



Photo 1



# Photo 2



# Photo 3

TABLE OF CONTENTS  
Illustrations: Page 4 through 18


|                           | <u>Subject</u>                                   | <u>Page No.</u> |
|---------------------------|--|-----------------|
| Preliminary<br>Operations | Unrating.....                                    | 19              |
|                           | Locating the Machine.....                        | 19              |
|                           | Cleaning.....                                    | 19              |
|                           | Foundation.....                                  | 20              |
|                           | Leveling.....                                    | 20              |
|                           | Lubrication.....                                 | 20              |
| Power<br>Connection       | Connecting Power Leads.....                      | 21              |
|                           | Electrical Hook-Up Procedure.....                | 22              |
| Machine<br>Operation      | Spindle (General).....                           | 22              |
|                           | Spindle Speed Setting.....                       | 23              |
|                           | Putting into Use.....                            | 23              |
|                           | Spindle--Hand Feed.....                          | 24              |
|                           | Spindle--Power Feed.....                         | 24              |
|                           | Power Feed Lubrication.....                      | 24              |
|                           | Table, Saddle, Knee--Hand Feed.....              | 24              |
|                           | Table--Power Feed.....                           | 25              |
| Lubrication.....          | 25   |                 |
| Machine<br>Adjustments    | RAM.....   | 25              |
|                           | Swivel.....                                      | 26              |
|                           | Turret.....                                      | 26              |
|                           | Cutter Spindle.....                              | 26              |
|                           | Spindle Bearings.....                            | 27              |
|                           | Spindle Brake.....                               | 27              |
|                           | Low Range Internal Drive Belt.....               | 28              |
|                           | Gibs.....  | 29              |
|                           | Feed Screws.....                                 | 30              |
|                           | Spindle Down Feed Unit.....                      | 32              |
|                           | Power Table Feed Unit.....                       | 32              |
|                           | Changing Feed Range Gears in Gorton Dyna-Drive.. | 35              |
|                           | Dyna-Drive Trouble-Shooting Procedure.....       | 36-A            |

# Photo 4

## TABLE OF CONTENTS (Continued)

|                           | <u>Subject</u>                          | <u>Page No.</u> |
|---------------------------|---|-----------------|
| Duplicating<br>Model      | Tracer Head.....                        | 37              |
|                           | Lubrication.....                        | 38              |
|                           | Adjustments.....                        | 39              |
|                           | Duplicator Table.....                   | 39              |
|                           | Lubrication.....                        | 40              |
|                           | Adjustments.....                        | 40              |
| Auxiliary<br>Equipment    | Coolant System.....                     | 41              |
|                           | Installation of Spindle Down Feed Unit. | 42              |
| Replacement<br>Parts List | Beginning on page.....                  | 44              |

# Photo 5




P 2741-M


## LEFT SIDE OF GORTON MASTERMIL

- |   |   |
|---|---|
| A. Terminal housing box on motor.                 | F. One of 3 swivel clamping nuts.                       |
| B. Eye bolt for lifting.                          | G. One-shot lubrication pump for table and saddle ways. |
| C. Swiveling mechanism adjustment bolt.           | H. Overload heater re-set button.                       |
| D. Power line to motor disconnected for shipment. | I. Socker head plug.                                    |
| E. Front and rear ram clamping bolts.             |   |


# Photo 6



# Photo 7



# Photo 8




P 2088-U

## REAR OF COLUMN

- A. Machine column.
- B. Coolant pump, motor and tank.
- C. Coolant compartment cover.



# Photo 9




P 2741-Q


## LEFT SIDE OF SWIVEL HEAD

- |  |   |
|--|---|
| A. Draw bar with back-up collar (left hand threads). | H. Spindle feed rate lever.                         |
| B. Motor mounting clamping bolt.                     | I. Spindle down feed engagement lever.              |
| C. Power spindle feed and retraction lever.          | J. Micrometer hand feed clutch lever.               |
| D. Slotted spindle brake shaft.                      | K. Spindle clamping lever.                          |
| E. Clamping screw.                                   | L. Micrometer hand feed crank with adjustable dial. |
| F. Set screw.  | M. Start button.                                    |
| G. Stop-brake lever.                                 |   |

# Photo 10



# Photo 11




P 2741-5

### SPINDLE REMOVAL — FIRST STEP

Refer to "Spindle Bearings" in Table of Contents

- A. Spanner wrench inserted in slots of spindle retaining ring (left hand threads).
- B. Wood blocks to protect spindle nose and table top.

# Photo 12




**SPINDLE REMOVAL — SECOND STEP**

P 2741-T


Refer to "Spindle Bearings" in Table of Contents

- A. Complete spindle assembly, including spindle, bearings, spacer, lock nut and washer.
- B. Spindle retaining ring.
- C. Spanner wrench.
- D. Wood blocks to protect spindle nose and table top.

# Photo 13




# Photo 14



**DYNA-DRIVE<sup>®</sup> LONGITUDINAL TABLE DRIVE** P 3121

- |   |                                       |
|---|---------------------------------------|
| A. Feed rate control.                   | G. Gear box and control unit housing. |
| B. Rapid traverse button.               | H. Motor and clutch housing.          |
| C. On-off switch.                       | J. Table power feed lever.            |
| D. Signal light.                        | K. Filters.                           |
| E. 4 cap screws holding cover in place. | L. Conduit box.                       |
| F. Frost cover.                         | M. Grease fitting.                    |


# Photo 15



# Photo 16


## TRACER SPINDLE-FRONT

- A. Two of 4 hex-head tracer head bolts.
- B. Tracer head assembly.
- C. Tracer draw bar.
- D. Tracer spindle.
- E. Micrometer vertical adjustment.
- F. Micrometer vertical adjustment locking lever.
- G. Tracer head tension spring.
- H. Spindle and tracer head hand feed lever.
- I. Spindle retraction adjustment collar.
- J. Tracer spindle guide key.
- K. Spindle nose retaining ring.
- L. Retaining ring clamping bolt.
- M. Spindle nose.



## TRACER SPINDLE-BACK


- A. Micrometer vertical adjustment housing clamping bolt.
- B. Clamping bolts, coupling tracer and cutter spindle feed shafts.
- C. Two of 4 hex-head tracer head bolts.
- D. Outer bearing set screw.







# Photo 18



P 2688-GG

## MASTERMIL EQUIPPED WITH TRACE-MASTER® HYDRAULIC TRACER CONTROL

The Gorton 1-22 Mastermil is available with Trace-Master hydraulic tracer control built in at the factory as original equipment. This can be furnished in 180° vertical feed; 360° longitudinal and cross feed, or 3D longitudinal, cross and vertical feed models. Gorton Trace-Master machines are excep-

tionally accurate and permit rapid duplicating of dies and molds as well as production profiling. If your machine is a Trace-Master model, supplementary instructions on the hydraulic installation have been supplied with this manual.



## Preliminary Operations

### Uncrating

1. After crating has been removed, examine carefully for shipping damage. Report at once to transportation company and to Gorton representative any evidence of such damage. Check shipment carefully against itemized packing list for possible shortages.

### Locating the Machine

(See page 4)

2. This machine is easily moved by hoist or shop crane. Loosen front and rear ram clamping bolts (front and rear of turret) and move head and ram with ram adjustment nut (right side of ram under "Mastermill" nameplate) so that approximately four inches of the rear of ram overhangs turret at back. Then tighten ram clamping bolts. Move table back against the column using cross feed handwheel. (See paragraph 6b.) Tighten saddle clamping lever under left end of table. (See page 6.) Place lifting hook in eye bolt on top of ram and move machine to its permanent location.

Note: If machine is equipped with hydraulic controls, move head and ram all the way forward as described above and move table to rear against column. Do not use eye bolt, but a double sling (2-inch rope) placed under ram adjacent to front ram clamping bolt.

3. If hoist or crane is not used, machine can be moved on rollers under shipping skid and lowered to floor with jacks and crowbars.
4. Machine is usually shipped with motor and motor pulleys dismounted. (See pages 8 and 9.) To remount, place motor flange on top of pulley housing flange with terminal housing box to rear. Engage motor mounting clamping bolt at left and spindle belt tension adjustment bolt at right. Install spindle belt and, after adjusting tension, tighten spindle belt tension adjustment bolt and motor mounting clamping bolt.

Important! Motor and pulleys have been carefully balanced and aligned. Do not remove pulleys at any time.

### Cleaning

5. Do not operate any moving part of this machine until it is thoroughly clean and has been given a coating of oil.

# Photo 21

Remove shipping grease with clean oilum spirits, or other grease solvent. Use lintless rags, not cotton waste. Never use an air hose. When machine is clean, give it a light coat of a good grade clean machine oil to prevent rust spots and other corrosion.

## Foundation

6. A solid foundation for this machine is advisable for satisfactory operation when doing heavy work or when running at high speeds. The following suggestions should be followed within the limitations of the building.
  - a. A 6-inch concrete foundation or floor is an ideal supporting base. When locating machine on a ground level floor of timber or composition, it is best to cut a hole and build a concrete foundation from the ground up to floor level. On upper floors, place machine directly over a supporting beam or upright pillar, if possible. Otherwise, locate machine close to a retaining wall. If concrete base is rough or uneven, it should be smoothed out by whatever method is most practical.
  - b. **Caution!** All locking or clamping levers are in locked position when machine leaves factory. They must be released before any attempt is made to move table, saddle or knee either manually or under power.

## Leveling Machine

7. After machine has been installed and cleaned, it must be carefully leveled. Make sure it is at room temperature before beginning to level. Use a sensitive, graduated spirit level (10 seconds per graduation) for best results. Level machine by placing level first lengthwise, then crosswise on the table and change the position of the table several times during the process. Remember that this machine must be re-leveled from time to time due to floor settlement.

## Lubrication

### See Page 18

8. All lubrication points are to be serviced with Gargoyle Vactra Oilheavy Medium X (a Socony-Mobiloil Product) at intervals determined by the requirements of the parts being serviced. **There are two exceptions.** The oil reservoir in the saddle should be kept filled with Gargoyle Vactra Oil No. 2, or way

oil, and the grease cup on the right side of the spindle pulley housing should be kept filled with Keystone Grease 122 Heavy. This is manufactured by the Keystone Lubrication Co., Philadelphia, Pennsylvania.

9. If machine is equipped with hydraulic controls to ram, table or knee or has a combination of two or more such controls, then Gargoyle Vactra Oil No. 4 must be used on the machine ways related to the hydraulic cylinders. The oil reservoir in the saddle must be serviced with No. 4 oil if the table is hydraulically controlled. Likewise a reservoir and one-shot pump on the left side of turret for ram ways and a reservoir and one-shot pump on the left side of knee for column must be similarly serviced.
8. Operator should apply sufficient oil to all ways on a hydraulically-operated machine to provide adequate lubrication at all times.
10. Cutter Spindle. This unit is permanently grease-sealed and requires no lubrication.
11. Micrometer depth Stop. The moving parts or threads of this unit should have a light coating of oil at all times.

#### Electric Motors

12. Spindle motor is grease-sealed and requires no lubrication. If machine is equipped with a coolant system, the coolant pump motor should be greased about every 1,000 hours of operation with a high grade ball bearing grease, such as Gargoyle Grease BRB No. 1. (A Socony-Mobiloil product.)

#### Power Connection

##### Connecting Power Leads

13. Caution! Do not attempt to reverse connections to any of the individual motors in the machine. It is essential that all motors and control equipment remain phased as they are wired and tested at the Gorton plant.
8. When multi-phase alternating current motors are used in the Gorton Mastermill, particular attention must be paid to correct phasing of power leads to assure correct operation of the electrical control equipment and direction of revolution of motors. The machines and control equipment are carefully tested and inspected before shipment.

to assure correct performance in the customer's plant. The electrician connecting up the machine must observe the following precautions to insure correct phasing of power leads and correct operating directions of motors.

#### Electrical Hook-Up Procedure

14. Connect line of correct voltage and phase to terminals in overload heater box or other control box (whichever was specified in your order). This is located on the left side of the column. Make these connections temporary until motor operating direction is checked.
  - a. When wiring motor, match colors of wires in flexible cable with colors of "battie tails" in terminal housing box on motor. Remove these "battie tails" before making final connections.
  - b. When spindle motor is started, spindle should revolve clockwise when looking down at it from above. If it rotates counterclockwise, reverse the power leads in overload heater box or control panel and again check direction of spindle rotation.
  - c. To assure full power, voltage at machine should be checked while machine is running and while all other electrical equipment on the same line is operating.

#### Machine Operation

##### Spindle

**Caution!** Before starting spindle, be sure that draw bar is removed or that it is firmly engaged in adapter, collet or outter to prevent serious accident.

15. To start spindle, pull spindle start-stop-brake lever forward and then return it to its neutral position. (See page 8.) To stop spindle, push lever to rear. To "brake" spindle, continue pushing to rear until spindle stops.

**NOTE:** Paragraph 15 applies to machines shipped prior to January, 1958. Machines shipped after January, 1958 have a starter button mounted on the front of the stop-brake lever housing, as shown on page 8. After starting spindle motor with this button, spindle is stopped and braked as described above.

##### Spindle Speed Settings

16. The spindle of the Mastermil has a dual speed range with ten speeds. To adjust for low range, pull out knob of range selector (see page 9) and turn down until plunger engages lower hole. For high speed range, engage plunger in upper hole.

**Note!** Always stop spindle before changing speed range setting.

- a. Speeds available in low range are; 80, 126, 216, 350 and 560 R.P.M. Speeds in high range are: 800, 1,260, 2,160, 3,500 and 5,600 R.P.M.
- b. To obtain any of the above speeds in its appropriate speed range, refer to the speed plate. (See page 9.) This shows correct belt positions for each speed.
- c. To change belt position, loosen both the spindle belt tension adjustment bolt at right and motor mounting clamping bolt at left. (See pages 8 and 9.) Pivot motor forward until belt is loose enough to re-position. After positioning belt, slide motor back to give proper belt tension and retighten both of the above bolts.
- d. If machine is equipped with power down feed to the spindle, the tension on the drive belt to the power down feed unit may need occasional adjustment. To loosen this belt, back off hex-head bolt under flange which supports the unit. This, of course, must be retightened after adjusting spindle belt to a light tension. When adjusting down feed unit belt, see that spindle belt is positioned in center grooves of motor and spindle pulleys.
- e. For accurate boring operations, adjusting screw (see page 9) should be tightened so that the quill action is slightly sticky. For high speed spindle work, adjusting screw should be loosened very slightly which will free up the vertical motion of the quill. For low speed heavy-duty work, the adjustment should also be tightened slightly.

Caution: Operator should be careful not to loosen cap screw "J" a great amount, which could cause the quill ring to move away from the lower end of the head casting. There is constant pressure against this quill ring from the quill spring, and it could be forced down from its shouldered position. If this should happen, a pair of parallels should be put onto the machine table, and the table elevated to push the quill ring back into place.

#### Putting into Use

17. Be sure inside of spindle nose is clean and dry. (See page 8.) When ready to put into service, insert draw bar into spindle from the top, then screw on the draw bar back-up collar (left-hand thread). Insert cutter in nose of spindle, making sure that shank is clean. Draw up cutter by turning square end with wrench while spindle brake lever is set until cutter is tight in spindle.



- a. To loosen cutter, set the spindle brake lever and apply wrench to square end; turn counter-clockwise. Initial movement loosens draw bar hold on cutter; continued movement forces cutter out of spindle nose. Do not use hammer on top of draw bar.

#### Spindle-Hand Feed

18. The machine is equipped with a hand feed lever on the right and a micrometer hand feed crank on the left side of spindle housing. (See pages 8 and 9.) The latter has a feed clutch lever located adjacent to the spindle clamping lever on left side of spindle housing, as well as an adjustable dial graduated in thousandths. To engage micrometer down feed crank, move feed clutch lever clockwise. To disengage, move it counter-clockwise.
  - a. A precision micrometer depth stop is mounted on the front of the spindle housing. It has a graduated scale and micrometer dial. This dial can be locked in any position by tightening the knurled micrometer depth stop lock in the center of the depth stop bracket.
  - b. To clamp spindle in place, pull spindle clamping lever out; push back to unclamp.

#### Spindle--Power Feed (See page 8)

19. If machine is equipped with power feed to the spindle, the following instructions will apply.
  - a. Before operating with power feed, be sure that the micrometer depth stop is set for correct depth of cut and that the feed clutch lever is engaged. Next, move spindle down feed engagement lever to rear to engage down feed unit.
  - b. Set down feed rate with spindle feed rate lever at bottom of down feed unit according to feed rates shown. Finally, move power spindle feed and retraction lever on top of down feed unit to its forward position and spindle will begin to feed down. To retract spindle under power, move this lever to the rear as shown on direction plate.

#### Power Feed Lubrication

20. Directions for lubricating this unit are on the feed rate plate.

#### Table, Saddle and Knee-Hand Feed

21. On the standard machine, the table, saddle and knee are hand fed by hand wheels or cranks in conjunction with adjustable

micrometer dials. (See page 6.) The table locking lever is located on the front of saddle; the saddle locking lever is located on the left end of saddle and under the table. The knee locking lever is located on right front of knee.

#### Table--Power Feed

22. If machine is equipped with a Dyna-Drive Infinitely Variable Power Feed Unit for the table, the following instructions will apply.
- a. **CAUTION:** Before operating this unit, it is necessary to remove the front cover and take out the packing material around the electronic tubes. (See page 13.) Four cap screws marked "E" should be loosened which will release the cover. Before replacing the cover, make sure that all tubes are firmly seated.
  - b. This unit provides infinitely variable table feeds within the feed range shown on the feed rate control plate "A". Power feed is controlled by power feed lever "J" on the front of saddle. This operates a feed clutch.
  - c. To operate Dyna-Drive Power Unit, turn "on-off" switch "C" to the "on" position. (It will automatically return to neutral position after power is on.) Signal light "D" will glow to indicate that the unit is activated. (It will take from 30 seconds to one minute for power feed unit to warm up and become operative.)
  - d. Set feed rate selector knob "A" at feed desired as shown on feed plate, and engage power feed lever "J".
  - e. For rapid traversing in either direction while power feed lever is engaged, push rapid traverse button "B" and hold in depressed position.

#### Lubrication

23. See page 13. The letter "M" on this photograph shows the location of the grease fitting for the Dyna-Drive Unit. Lubricate once a week, three (3) shots of #122 Keystone grease. Motor bearings in Dyna-Drive Unit are permanently greased and sealed.

#### Machine Adjustments

##### Ram

24. With open end wrench furnished with machine, loosen front and rear ram clamping bolts. Ram adjustment is made with socket wrench also furnished applied to the ram adjustment

# Photo 27

bolt on right side of ram. Be sure to retighten front and rear ram clamping bolts after ram adjustment.

## Swivel

25. The Mastermil has a swivel head with an index ring located between spindle head and ram. This ring is graduated 90° left and right.
- To swivel head, loosen the three clamping bolts adjacent to index ring. (See pages 4 and 5.) With socket head wrench, turn either swivel mechanism adjusting bolt (on either side of ram near the top) until head is at required angle and then reclamp with the three clamping bolts.
  - To bring head back to the vertical position, reverse the above procedure. For close work, attach dial indicator to spindle nose and sweep table to assure true vertical position of spindle.

## Turret

26. Turret is clamped to top of column by a triangular "spider" held in position by a large center bolt which never needs adjusting. To loosen turret for adjustment, use open end wrench furnished and loosen hex head bolt just inside opening in rear of column, just below rear ram clamping bolt. Turret may now be positioned manually and the hex head bolt retightened.
- To return turret to "0", match index lines on left side of column and turret at the juncture of these two members.

## Cutter Spindle

27. The cutter spindle is non-adjustable; it requires no attention and is permanently lubricated. If an irregular pattern develops during face milling, or if play should develop after a long period of service, the super-precision preloaded ball bearings should be replaced by bearings of the same type from the George Gorton Machine Co., which will put the spindle in "like new" condition.
- The cutter spindle is mounted on two sets of preloaded super-precision ball bearings, forming a complete unit which may be removed.

Note: It is strongly recommended that spindles requiring service be returned to the factory for expert attention. However, if it is necessary to replace bearings in the field, the following instructions will apply.

### Spindle Bearings

28. **Caution!** Before following the instructions below, move speed range selector lever to the "up" position and keep it there during the following operations.
  - a. Put match marks on spindle top and upper pulley with grease crayon. When replacing spindle, align these match marks.
  29. Place two short 2"x4" wood blocks on machine table under spindle nose. (See page 10 and 11.) Engage spanner wrench in slots in spindle retaining ring and turn to right (left-hand thread). When ring is removed, the spindle, spacer, bearings, grease retaining ring, tang lock washer and lock nut can be withdrawn downward as a unit.
    - a. To dismantle spindle assembly, release tang lock washer and unscrew lock washer (right-hand thread). Remove nut, washer and grease retaining ring. Finally, slide upper pair of bearings, the spacer and lower pair of bearings off the top of the spindle. To hold assembly in place during this time, clamp splined section of spindle in a protected vise.
    - b. To install new bearings, place the stamped faces of the two large bearings together and slide onto the spindle and push to spindle nose. Follow this with the spacer, then the two smaller bearings also with stamped faces together. Be sure that "balance marks" on both pair of bearings match.
    - c. Bearings should slide on spindle with a light push fit. Reinstall grease retaining ring, tang lock washer and tighten lock nut firmly. Be sure lock nut is engaged by one tang on tang lock washer. Put spindle bearings in V-block and, by turning spindle, check splined end for runout. Now re-install spindle assembly by reversing procedure in paragraph 29 above.

### Spindle Brake Adjustment (Machines prior to Jan. 1958)

30. The start-stop-brake lever actuates two limit switches to start and stop spindle motor plus a brake shoe which exerts a clamping action on a flange on the bottom spindle

pulley. All adjustments for satisfactory operation are made and tested at the factory but occasionally, after some use, an adjustment of this unit may be necessary.

- a. In following the instructions contained in paragraph 15, if brake operates before current is cut off by the "off" limit switch, the following will apply. (See page 8.)
- b. Loosen the screw which clamps the start-stop-brake lever to the horizontal shaft. Now loosen set screw in front of start-stop-brake lever casting which leads to this same horizontal shaft. Now hold brake lever in vertical-neutral-position and use screwdriver in the slot in end of horizontal shaft. Turn counterclockwise  $1/8$  of a turn, then tighten both set screw and clamping screw. (In all cases the set screw must engage inside mating hole.) Now try the start-stop-brake lever in starting, stopping and braking the spindle. If brake is still too tight, repeat the above adjustment to loosen it a bit more, etc.
- c. If brake is too loose, it will not bring spindle to a quick stop when start-stop-brake lever is pushed clear back. In this event, follow the above procedure but turn slotted spindle brake shaft clockwise in  $1/8$ th turn steps.

Caution: Never flip or snap the start-stop-brake lever. Always pull forward to start and then return it to neutral. The same procedure should be followed when stopping and braking.

#### (Machines after Jan. 1958)

- d. On these machines the spindle is started by push button located on the front of stop-brake lever housing. Spindle is stopped by pushing stop-brake lever to rear. To "brake" spindle, push to extreme rear position. Stop and brake adjustments are the same as those covered in paragraphs 30, a, b, and c. No start adjustments are required.

#### Replacement of Low Range Internal Drive Belt

31. Inside the lower section of the spindle pulley housing is the low range internal drive belt. While this notched belt operates at all times, it exerts driving power to the spindle only in the low speed range. To replace this belt, the following instructions should be followed.
- a. Turn off all power at the control panel. Next, remove spindle belt. In case the machine is equipped with power down feed for the spindle, remove this belt also.

- b. Remove motor with motor pulleys as a unit. Reverse procedure described in paragraph 4. To avoid the necessity of disconnecting power line to motor, move machine table to column face and to its upper position; cover with a board and put motor (upside down) on the board. (See page 12.) You have now exposed the top of spindle, pulleys, vertical jack shaft, three cap screws surrounding the jack shaft and the snap ring at top of jack shaft.
- c. Remove snap ring from top of jack shaft and loosen the three cap screws. Make sure that the plunger in the speed range selector lever is pulled out during the next step.
- d. Remove the four cap screws (one at each corner) holding the upper and lower sections of the pulley housing together. Mark top of spindle and spindle sleeve with match marks to be used later in re-assembly. Lift and pry upper section of belt housing straight up so as not to damage the two dowel pins. During the removal of upper section of pulley housing, make sure you do not develop any burrs along the mating edges. If so, file smooth. Invert the section just removed and place on machine table.
- e. If large drive pulley has two flanges, pry the lower one (now in the upper position) off and remove old belt by pushing pulley toward spindle pulley. Install new belt and discard the flange which was removed. (In case there are no flanges on the drive pulley, this operation is even simpler. Merely push toward spindle pulley and remove belt.)
- f. To re-assemble, reverse the above procedure. Be sure, when re-installing upper section on lower section, that the key on the jack shaft slides into its keyway as the two sections come together. Also match the marks you made on top of spindle and spindle sleeve.

#### Gibs

32. Correct gib adjustments depend almost entirely upon judgment and "feel". If adjustment is too loose, loss of machine accuracy results. Too tight an adjustment squeezes out all lubricant and sliding ways are then subject to excessive wear and scoring.

## Table Gib

- a. This gib is located under the front table bearing slide with the large end at right. There is an adjusting screw here and another at the small end. To adjust, when table gib is loose, back off adjusting screw at the small end of gib one-half turn. Tighten screw at large end of gib one-quarter turn. Next, tighten screw at the small end of gib until snug. Try table movement. Repeat to get desired adjustment. To adjust when table gib is too tight, reverse this procedure.

## Saddle Gib

- b. The saddle gib is located on the left-hand side of saddle next to knee center guide. The large end of the gib is at front. Adjust this gib as described in paragraph 32a above.

## Knee Gib

- c. The knee gib is located on the right-hand side of the knee directly behind the column dovetail with the small end at top. Gib adjustment is the same as described in paragraph 32a above.

## Feed Screws

### Table Screw

33. To adjust for backlash between table screw and nut, locate backlash adjustment under left end of table. Loosen the two socket head locking screws on table screw nut and move nut in a clockwise direction to a snug fit. Re-tighten locking screws and try table feed screw. Correct adjustment will result in from .002" to .003" movement of table screw.

### Saddle Screw

34. If too much play eventually develops between the saddle screw and saddle nut, it will be necessary to replace the saddle screw and nut assembly. This is necessary to provide perfect factory fit between the nut and screw. Where shop hoist is available, the following instructions will apply.

# Photo 32

- a. First, drive out roll pin attaching left-hand wheel to screw shaft. Remove handwheel. Loosen thumb screw on graduated dial and remove it. Disengage tang of tang lock washer and remove lock nut and tang lock washer. Next, turn handwheel at right end of table counterclockwise until ball bearing and snap ring at left end of screw come free. Remove ball bearing and snap ring. (If your machine is equipped with Dyna-Drive table feed unit, remove left-hand handwheel which is not dowelled. Drive roll pin out of spacer collar and put handwheel on right-hand end of screw shaft.)
- b. Now, remove four cap screws in right-hand table bracket and clamp table with table clamping lever. Next, turn right-hand table handwheel counterclockwise; end bracket will pull loose from table. Continue turning handwheel until table screw is free of table screw nut. This will permit removal of handwheel assembly, table bracket and screw.
- c. Remove table gib adjusting screw at large end of gib--do not touch screw at other end. Remove gib. Table may now be slid to left until it can be lifted free by three men or shop hoist.
- d. Now, pull saddle screw handwheel off of shaft. Loosen thumb screw on graduated dial and remove. Next, remove three cap screws exposed. Clamp saddle securely with saddle clamping lever and, with handwheel re-installed, turn in clockwise direction until saddle screw is released from saddle screw nut. Remove screw assembly.
- e. Inside the saddle are four cap screws which hold the cross feed screw nut to the saddle. Remove these cap screws and gently pry the nut assembly loose so that it can be removed.
- f. With a spanner wrench, remove locking ring from front of nut (right-hand thread) and tap old nut out of casting. Also remove roll pin from casting.
- g. Replacement parts consist of a new cross feed screw, nut and roll pin. Insert new nut in casting, threaded section to the front. Install locking ring and tighten with spanner wrench. Drill 3/16" hole through rear flange of nut and into casting and pin with new roll pin. Replace nut assembly in saddle and bolt in place with four cap screws. If dowels fit too loosely, redowel with oversize dowel pins, after testing with new screw in place.
- h. Now, loosen tang in tang lock washer, remove lock nut and bearings from old feed screw shaft. Re-install on new feed screw.



**Caution!** Be sure to have stamped outer faces of bearings together when installing bearings on shaft.

1. Insert screw in front of knee. Engage nut and turn counter-clockwise until assembly is firmly seated. Reverse procedure described in paragraph 34d to complete installation of cross feed screw.
1. To re-install table, reverse the procedure explained in paragraph 34a through 34c.

#### 1235-1 Spindle Down Feed Unit

35. If machine is equipped with the above unit and internal adjustment or repair is ever required, remove the entire unit and return to factory for replacement or repair. (See page 8.) The down feed unit and mounting bracket should be removed as a unit by taking out the five cap screws holding bracket to the machined pad on the left side of spindle housing.
  - a. If a machine is operated while unit is removed, be sure to provide a temporary cover for the opening in spindle housing to keep out dirt and moisture.
  - b. When re-installing feed unit, it may be necessary to redowel it with slightly larger dowel pins.

#### Power Table Feed Dyna-Drive Unit

36. If machine is equipped with a Dyna-Drive Infinitely Variable Power Feed Unit for the table, the following instructions will apply.
37. The following are suggestions for remedial action if Dyna-Drive Unit requires minor service or adjustments. It is recommended that an electrician make such adjustments. (See page 13.)
  - a. **SYMPTOM:** On-off switch is turned on but signal light remains out and unit does not start.

**REMEDY:** Pull Start-Stop-Brake lever on spindle housing to see if spindle motor starts. If not, check control circuit fuse and press all reset buttons. If this procedure fails, check main power line and fuses.

- b. **SYMPTOM:** Dyna-Drive motor operates but electronic control assembly is inoperative.

**REMEDY:** (See page 14.) Remove front cover and make sure all tubes are lit. If not, replace faulty tubes. (All tubes must be seated firmly.)

**CAUTION:** As with any electronic unit, it is advisable to have spare tubes readily available.

If tubes are functioning, check brake fuse "C" and clutch fuse "D". Replace if required. Brake fuse is type 3AG, 1/2 ampere; clutch fuse is type 3AG, one ampere. (Do not use fuses of greater capacity--tubes will burn out.)

If fuses are functioning, a check should be made for faulty connections in conduit box "L"; special attention should be given to wires 13 and 14 coming from machine control panel to "on-off" switch.

Also check wires 11 and 12 for approximately 150 V., A.C. If voltmeter does not read close to 150 volts, then the entire Dyna-Drive power feed unit should be returned to factory for repairs. (All voltage readings should be made at power socket "M" on page 14.)

To remove Dyna-Drive Unit from machine saddle, refer to page 13. The unit is attached to the under side of saddle as shown. First, disconnect power leads which enter the control box on the left side of column. Pull cable through column until it is free.

Remove front cover of Dyna-Drive Unit by taking out four cap screws "E", page 13. Shore up unit from the floor. Remove two cap screws going through the top of gear box and control unit housing "G", and two cap screws at rear going through flange into the saddle. This will release the entire Dyna-Drive Unit.

Replace front cover on Dyna-Drive Unit before returning to factory. Be sure to put adequate packing around the tubes.

To re-install the Dyna-Drive Unit after factory servicing, reverse the above procedure by locating the keyway in the lower part of the sleeve in the saddle, so that the key at the end of the Dyna-Drive shaft will engage it as the unit is raised and bolted into place.

- c. **SYMPTOM:** Power feed unit operates erratically; feed rate varies, or there is no feed at all at low settings--or, if table coasts at high rate of feed after rapid traversing, then follow the suggestions below.

# Photo 35

**REMEDY:** See page 13. Erratic feed rate or no feed rate at all at low settings; first set feed rate control knob at zero.

Loosen lock nuts "E" on clutch potentiometers and rotate potentiometer fully counterclockwise with screwdriver.

To adjust clutch, connect an 0-150 A.C. voltmeter to the clutch fuse "C" and chassis. Rotate the clutch "E" potentiometer slowly clockwise until a downward deflection is noted on the meter, then back up counterclockwise slightly until meter deflection is normal. The amount of back-up is critical. (Page 14.)

If the potentiometer is rotated back too far from the point of meter deflection, the servo amplifier loses sensitivity. If it is not backed up enough, the table feed will not be stopped when potentiometer is on zero.

Following above adjustments, tighten lock nut "E".

After above adjustments have been made, engage power feed lever "J" (page 13) and leave feed rate control knob at zero. Now depress rapid traverse button "B" and release. If machine table coasts for more than approximately one second, the following suggestions will apply.

Check wires 12 and 13 for faulty connections.

Replace brake power tube 2D21 at "F" (page 14). If this does not remedy the defect, replace control amplifier tube 12AU7 at "H". The Dyna-Drive Unit should now perform properly. If it does not, replace the entire electronic control assembly as follows:

Disconnect plug "L" (page 14) and socket "M".

Remove two screws under the gear box and control unit housing "G" (page 13) near front. These hold the electronic control assembly in place.

Lift out electronic control assembly and replace from dealer's stock or direct from factory.

- d. **SYMPTOM:** Regardless of feed rate control knob setting, the unit runs continuously at the high feed rate.


**REMEDY:** First, determine if main power lines to the control box are connected correctly to rotate the spindle clockwise when looking down at it from above. If not correctly connected, the Dyna-Drive will operate as just described.







# Photo 39



Die and Mold Duplicating Model

Tracer Head

39. If your machine is a Mastermill die and mold duplicator, the tracer head has already been properly installed at factory. If, however, your machine is a standard Mastermill, the following instructions will explain how to install, operate and adjust the tracer head. (See page 15.)
- a. On the right side of the spindle housing where the speed shaft protrudes, there is a square pad which has been machined, drilled and tapped to take the 1018-1 Gorton duplicator tracer head.
  - b. Remove the hand feed lever at right of spindle.
  - c. Remove tracer spindle guide key located in the milled vertical slot in tracer spindle housing. This permits drawing out the entire spindle assembly from the tracer spindle housing. Remove tension spring. Next, loosen outer bearing set screw in top of tracer spindle housing and remove hand feed lever shaft complete.
  - d. Examine surfaces of mounting pads--wipe clean and remove any burrs. Mount tracer head shaft housing on pad on spindle housing with four hex head tracer head bolts, furnished with tracer head assembly. Replace tracer spindle assembly in tracer spindle housing without tension spring. Allow this assembly to seat itself in its lowest position. Clamp dial indicator to tracer spindle nose.



# Photo 41

for 10" sweep of table. Sweep the machine table. Tolerance should be from .0005" to .001", depending upon individual requirements.

- e. After noting deviations from required tolerances, the top or bottom of the tracer head mounting face should be scraped to bring tracer spindle to the position required. To compensate for any front-to-back error, rotate the tracer head casting either clockwise or counterclockwise on the machined pad. When correct position has been located, tighten the four hex head tracer head bolts firmly.
- f. Now drill two 5/16" dowel holes in spindle housing, using pilot holes in tracer mounting bracket as guides. Holes should be reamed for press fit in pad and push fit in mounting bracket. Insert and press home two dowel pins. Re-assemble tracer spindle assembly with tension spring. Insert in tracer spindle housing and replace tracer spindle guide key.
- g. Make sure that clamping bolts in coupling at end of tracer spindle feed shaft are loose. Remove coupling and mount on end of cutter spindle feed shaft. Now, remount tracer spindle feed shaft and tighten outer bearing set screw. Lock the cutter spindle in the up position. Install hand feed lever on end of tracer spindle feed shaft and lock in up position.
- h. It is now necessary to connect the tracer spindle to the cutter spindle through its feed shaft in such a way that the positive upper cutter spindle stop will also act as a stop for the tracer spindle. The tracer spindle guide key should never be used as a stop.
- i. Position the tracer spindle with the guide key approximately 1/4" below its upper limit. With the tracer spindle in this position, center the two clamping bolts coupling tracer and cutter feed shaft in the cored holes at back of tracer head housing. Tighten these bolts firmly. Release spindle locking lever. The tracer spindle is now ready to use.

## Lubrication

40. There is an oil hole at rear in the top of the casting at upper end of tracer spindle. This should be oiled daily with medium machine oil. There is an oil cup on the front of the tracer spindle housing at the top. This should be filled daily with spindle oil. There is also an oil cup on top of the tracer head outer bearing. This should be filled daily with medium machine oil. A few drops of oil should occasionally be applied to the threaded portion of the tracer spindle.

## Adjustments

41. There are two vertical adjustments which can be made to compensate for differences between the work piece and master. The first or rough vertical adjustment is made by first locking the cutter spindle and loosening the outer clamping bolt coupling tracer and cutter spindle feed shafts. Use tracer hand feed lever to position tracer spindle nose. Re-tighten clamping bolt. Fine adjustments are made with the micrometer vertical adjustment.

## Duplicator Table--See Page 16

42. If this machine is a Mastermill die and mold duplicator, the duplicator table was mounted on the machine table at the factory. If, however, this machine is a standard Gorton Mastermill, the following instructions will apply.
  - a. Be sure to remove right-hand adjustable stop dog on machine table and lay it aside or park it next to the left-hand adjustable stop dog at the extreme left end of table slot.
  - b. When mounting or dismounting the duplicator table on or off of machine table, a shop hoist or crane should be used. Use heavy rope, not chain or wire cable. Locate duplicator table with the "U" slots at either end over machine table "T" slots. Lower gently and clamp in place, being sure that keys on the underside of duplicator table base are engaged in the center "T" slot of machine table.
  - c. The duplicator table assembly is made up of: 1) the duplicator table proper (heat-treated aluminum alloy); 2) the master table and base with micrometer adjusting screws and clamping bolts; 3) saddle which, with the duplicator table, makes possible longitudinal motion; 4) duplicator table base which, with the saddle, makes possible the cross or transverse motion; 5) manual duplicating control lever attached to the two drop arms.
  - d. Locate work piece on the duplicator table with its center under the center of the cutter spindle. Two methods of clamping the work piece are available. Two 1/2" "T" slots running longitudinally 1-5/8" either side of center may be used or any of the sixteen tapped holes for 7/16" hold-down studs. If "T" slots are used, Gorton type (elongated) nuts should be used to prevent distortion of table top.

# Photo 43

- e. Mount the master, pattern or template on the master table and clamp in place. Next, loosen the two master table clamping bolts and position master table so that center of the master is under the center of the tracer spindle. Tighten the master table clamping bolts. For final positioning, the two master table micrometer adjusting screws may be used.
- f. To provide free movement of the duplicator table in all directions, remove table and saddle locking bolts and plug the holes. Loosen longitudinal clamping studs and remove "U" strap. If cross movement only is desired, leave this "U" strap clamped tightly in place. If longitudinal movement only is desired, remove "U" strap and insert from below on the cross feed clamping studs, then tighten the studs.
- g. For operator convenience, the manual duplicating control lever is adjustable for height by loosening lever extension sleeve adjustment bolt with Allen wrench.

## Lubrication

43. In the duplicator table top are four oil pipe plugs marked "oil". These serve the endless stream of ball bearings on which the table moves. Oil once a week with spindle oil in an amount sufficient to come up to the oil pipe plug.
- a. On the front and back of the saddle are two oil cups which serve the endless stream of ball bearings on which the saddle moves. Lubricate as described in paragraph above. **CAUTION.** It is extremely necessary that no grit or foreign matter is permitted to get into the oil pipe plugs in table top or into the oil cups on front and rear of saddle.
- b. The oil cup on the upper ball and socket joint at the bottom of the right-hand drop arm should be lubricated with medium machine oil daily. In addition, a few drops of oil should be applied to the master table micrometer adjusting screw threads.

## Adjustments

44. Duplicator friction brake. This is located at right on duplicator table base. If less braking action is desired, the brake adjusting nut is turned down. If more braking action is required, turn it up.
- a. To adjust for looseness in table, loosen the two screws in the two ball bearing return blocks at back of table. Loosen the five hold-down bolts on top of ball track. Loosen two

# Photo 44

jamb nuts on adjustable table gib and take up on the two gib adjusting screws. All loosening and tightening in this operation should be uniform. Now tighten jamb nuts and retighten the five hold-down bolts on top of ball track together with the two screws in the top of both ball bearing return blocks. Check for continued looseness with dial indicator. Looseness is indicated by "snap" movement of needle. Slow needle movement indicates distortion, not looseness.

- b. To adjust for looseness between saddle and base, follow the same procedure as described immediately above with the ball tracks running crosswise between saddle and base.
- c. After gib adjustments, check the joints between ball bearing return blocks and the ends of the ball races to see that they are tight so that no foreign matter can get into ball races.
- d. If table ball bearings become "sticky" after continued use, it is desirable to flush them thoroughly with kerosene. Remove the four oil pipe plugs in table top and flush until balls operate freely. Move table continually while flushing. Re-lubricate with spindle oil until oil has replaced kerosene. In the case of the saddle balls, follow the same procedure, using the two oil cups on the front of the saddle and the two on the rear.

## Auxiliary Equipment

### Coolant System

45. If machine includes a coolant system, access to the coolant pump, motor and tank is through coolant compartment cover at rear of column. To put into operation, fill coolant tank up to fill mark on pump casting. Press coolant motor starting button so marked on control panel. Coolant should flow when nozzle is turned on.
  - a. If a coolant system is to be installed in the field, the following instructions will apply. (See page 4 and 7.)
  - b. On the left side of the column below and to the left of the overload heater box, you will find a hole into which the return coolant line goes from the left end of machine table. Another hole is provided in the top of the column way section of the column at left front.
  - c. Install coolant tank and pump through opening at rear of column base with pump unit entering first. Attach coolant feed line after dropping connection end through upper hole in column casting. Make connection to vertical feed pipe of pump.

- d. Remove socket head plug in the left-hand table and bracket and make connection with coolant return line. Insert other end of return line in lower hole in column casting and insert end of line in coolant tank.
- e. Have electrician hook pump motor to power supply and have him check for correct rotation of pump motor. This is indicated by arrow on housing.

#### Lubrication

- f. See paragraph 12.

#### Adjustments

- g. None.

#### Field Installation of 1235-1 Spindle Down Feed Unit

46. In case you order the above unit for installation on your Masterall, complete instructions and drawings will be furnished with the unit to make such installation easy.

# Photo 46

## Parts List


The following pages are furnished for ready identification of all parts in the various assemblies. This section is arranged in the same order as the preceding section, viz:

1. Standard Gorton Mastermill
2. Duplicator Tracer Heads
3. Duplicator Tables

## IMPORTANT

Always furnish the serial number and/or model number of machine, duplicator table or tracer head when ordering replacement parts. Serial numbers on Gorton Mastermills and duplicators are located on nameplate on left-hand side of column and on column underneath medallion on left side of column. Serial numbers on Gorton duplicator tables are located on front edge of table base at left end. Model numbers for tracer heads are located on top of the tracer head feed shaft housing.


Photo 47








# Photo 49





# Photo 51



# Photo 52

PARTS LIST - - GORTON L-22 MASTERWILL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

RAN


Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig No. | Part Name                      | Part No. | Fig No. | Part Name | Part No. |
|---------|--------------------------------|----------|---------|-----------|----------|
| 1       | Hexagon Nut (2)                | K-6009   |         |           |          |
| 2       | Not Used                       |          |         |           |          |
| 3       | Spindle Head T-Bolt (3)        | 21143    |         |           |          |
| 4       | Set Screw (2)                  | K-3628   |         |           |          |
| 5       | Roll Pin (2)                   | K-5562   |         |           |          |
| 6       | Speed Plate                    | K-3718   |         |           |          |
| 7       | Drive Pin (4)                  | K-423    |         |           |          |
| 8       | Head Adjusting Shaft Collar(2) | 21138    |         |           |          |
| 9       | Ball Thrust Bearing (2)        | KB-44    |         |           |          |
| 10      | Head Adjusting Shaft           | 21137    |         |           |          |
| 11      | Spacer                         | 21160    |         |           |          |
| 12      | Head Adjusting Worm            | 21141    |         |           |          |
| 13      | Roll Pin                       | K-5562   |         |           |          |
| 14      | Socket Pipe Plug               | K-406    |         |           |          |
| 15      | Eye Bolt                       | 11512    |         |           |          |
| 16      | Taper Pin                      | K-491    |         |           |          |
| 17      | Back Pinion                    | 7857     |         |           |          |
| 18      | Dog Point Socket Set Screw     | K-6005   |         |           |          |
| 19      | Back Pinion Shaft              | 21136    |         |           |          |
| 20      | Nameplate (2)                  | 21295    |         |           |          |
| 21      | Drive Pin (4)                  | K-6228   |         |           |          |
| 22      | Socket Wrench                  | K-6151   |         |           |          |
| 23      | Ran                            | 21131    |         |           |          |
| 24      | Cord Grip (4)                  | K-6086   |         |           |          |
| 25      |                                |          |         |           |          |
| 26      |                                |          |         |           |          |
| 27      |                                |          |         |           |          |
| 28      |                                |          |         |           |          |
| 29      |                                |          |         |           |          |

( ) Figures in parentheses indicate quantities of identical part

2741-D

# Photo 53



# Photo 54

## PARTS LIST -- GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


### SPINDLE HOUSING

Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig No. | Part Name                             | Part No. | Fig No. | Part Name                              | Part No. |
|---------|---------------------------------------|----------|---------|--|----------|
| 1       | Internal Drive Belt                   | K-6082   | 52      | Hex Head Cap Screw for above/Not Shown | K-266    |
| 2       | Bell Bearing Lock Nut                 | K-1369   | 54      | Socket Head Cap Screw (4)              | K-153    |
| 3       | Bell Bearing Lock Washer              | K-95     | 57      | Head Adjusting Worm Wheel              | 21142    |
| 4       | Small Internal Drive Belt Pulley      | 21231    | 58      | Graduated Ring                         | 21198    |
| 5       | Spindle Gear Bearing Retainer         | 21217    | 59      | Socket Set Screw                       | K-259    |
| 6       | Large Internal Drive Belt Pulley      | 21289    | 60      | Socket Cap Screw                       | K-169    |
| 7       | Snap Ring                             | K-5930   | 61      | Spindle Barrel Bushing                 | 21148    |
| 8       | Snap Ring                             | K-3957   | 62      | Feed Stop Bracket                      | 21125    |
| 9       | Snap Ring                             | K-6076   | 63      | Socket Cap Screw (2)                   | K-153    |
| 10      | Woodruff Key (2)                      | K-5435   | 64      | Thumb Screw Spring                     | 6415     |
| 10a     | Key                                   | 21988    | 65      | Thumb Screw                            | 6307     |
| 11      | Counter Shaft                         | 21987    | 66      | Round Head Machine Screw (2)           | K-6122   |
| 12      | Spindle Idler Gear                    | 21892    | 67      | Depth Stop Scale                       | 21203    |
| 13      | Bell Bearing (1 set)                  | KB-3075  | 68      | Feed Stop Micrometer Screw             | 21200    |
| 14      | Spindle Pulley Sleeve                 | 21191    | 69      | Socket Set Screw                       | K-187    |
| 15      | Key                                   | 18049    | 70      | Instruction Plate                      | K-6145   |
| 16      | Taper Pin                             | K-471    | 71      | Drive Pin (4)                          | K-423    |
| 17      | Speed Range Lever                     | 21221    | 72      | Feed Stop Micrometer Collar            | 21201    |
| 18      | Lever Handle                          | 7638     | 73      | Oilite Bearing                         | K-6085   |
| 19      | Taper Pin                             | K-461    | 74      | Feed Stop Micrometer Wheel             | 21202    |
| 20      | Speed Range Lever Bushing             | 21222    | 75      | Grease Cap and Tube                    | CP-1933  |
| 21      | Lever Plunger                         | 7639     |         |  |          |
| 22      | Spring                                | 11428    |         |  |          |
| 23      | Button Head Screw (2)                 | K-6075   |         |  |          |
| 24      | Dowel Pin (2)                         | K-6545   |         |  |          |
| 25      | Range Lever Index Plate               | 21228    |         |  |          |
| 26      | Slitter Shaft Bushing                 | 21227    |         |  |          |
| 27      | Socket Set Screw                      | K-5409   |         |  |          |
| 28      | Bell Bearing Lock Nut                 | 10231    |         |  |          |
| 29      | Bell Bearing (2)                      | KB-6077  |         |  |          |
| 30      | Countershaft Gear                     | W-21891  |         |  |          |
| 31      | Dog Point Socket Set Screw            | K-4076   |         |  |          |
| 32      | Bearing Spacer (Inner)                | 21984    |         |  |          |
| 32a     | Bearing Spacer (Outer) Not Shown      | 21985    |         |  |          |
| 33      | Bell Bearing Housing Housing (2)      | KB-6358  |         |  |          |
| 34      | Idler Gear Shaft                      | 21983    |         |  |          |
| 35      | Snap Ring                             | K-6076   |         |  |          |
| 36      | Idler Gear Shaft                      | 21205    |         |  |          |
| 37      | Button Head Screw (3)                 | K-6074   |         |  |          |
| 38      | Bearing Retaining Guide               | 21215    |         |  |          |
| 39      | Spindle Hopper Stop                   | 21216    |         |  |          |
| 40      | Low Speed Spindle Gear                | 21220    |         |  |          |
| 41      | Counterbalance Spring                 | 21224    |         |  |          |
| 42      | Gear Shift Shaft                      | 21223    |         |  |          |
| 43      | Not Used                              |          |         |  |          |
| 44      | Not Used                              |          |         |  |          |
| 45      | Gear Slitter Arm (2)                  | 22117    |         |  |          |
| 46      | Roll Pin (2)                          | K-6405   |         |  |          |
| 47      | Taper Pin (2)                         | K-6406   |         |  |          |
| 48      | Dowel Pin (2)                         | K-6545   |         |  |          |
| 49      | Socket Cap Screw (2) 1/4" long        | K-152    |         |  |          |
| 50      | Socket Cap Screw (2) 1" long          | K-151    |         |  |          |
| 51      | Snap Ring                             | K-5336   |         |  |          |
| 52      | Oil Cap                               | K-3132   |         |  |          |
| 53      | Spindle Head                          | 21170    |         |  |          |
| 54      | Countershaft Bearing Washer Not Shown | 21981    |         |  |          |

( ) Figures in parentheses indicate quantities of identical parts

# Photo 55



# Photo 56

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


Always Give  
Machine Model Number  
and SERIAL NUMBER

| PULLEY HOUSING |                                |          |         |  |          |
|----------------|--------------------------------|----------|---------|--|----------|
| Fig No.        | Part Name                      | Part No. | Fig No. | Part Name  | Part No. |
| 1              | Spindle Motor                  | E-1148   | 29      | Start-Stop Brake Lever                                     | 21176    |
| 2              | Spindle Belt                   | K-6374   | 30      | Spring   | 21256    |
| 3              | Spindle Pulley                 | 21172    | 31      | Socket Set Screw   | K-2503   |
| 4              | Cord Grip (2)                  | K-6161   | 32      | Woodruff Key   | K-4495   |
| 5              | Hex Head Cap Screw (2)         | K-6153   | 33      | Start-Stop-Brake Lever Bushing                             | 21159    |
| 6              | Washer (2)                     | 12973    | 34      | Brake Screw  | 21175    |
| 7              | Socket Set Screw 5/16" Long    | K-189    | 35      | Brake Shoe Assembly - Right Head (Includes No's 36 and 37) | CP-1931  |
| 7a             | Socket Set Screw 1/2" Long     | K-2006   | 39      | Brake Shoe Assembly - Left Head (Includes No's 36 and 38)  | CP-1932  |
| 8              | Motor Pulley                   | 21173    | 40      | Snap Ring  | K-6146   |
| 9              | Snap Ring                      | K-3963   | 41      | Interlock Bushing  | 21165    |
| 10             | Ball Bearing                   | KB-6078  | 42      | Steel Ball   | K-76     |
| 11             | Bearing Housing                | 21213    | 43      | Spring   | 22102    |
| 12             | Hex Head Cap Screw (3)         | K-255    | 44      | Switch Cam   | 21257    |
| 13             | Shake-Proof Washer (3)         | K-5192   | 45      | Inner Bearing Spacer                                       | 21193    |
| 14             | Pulley Housing                 | 21171    | 46      | Ball Bearing (1 set)                                       | KB-6009  |
| 15             | Pulley Housing Conduit         | 21166    | 47      | Outer Bearing Spacer                                       | 21194    |
| 16             | Elbow                          | K-6113   | 48      | Bearing Retaining Nut                                      | 21192    |
| 17             | Socket and Cap Screw (3)       | K-6068   |         |  |          |
| 18             | Switch Plate Cover             | 21169    |         |  |          |
| 19             | Round Head Machine Screw (4)   | K-1347   |         |  |          |
| 20             | Microswitch (2)                | E-2421   |         |  |          |
| 21             | Switch Insulating Plate (2)    | 21151    |         |  |          |
| 22             | Switch Mounting Plate          | 21181    |         |  |          |
| 23             | Socket Cap Screw (4)           | K-1991   |         |  |          |
| 24             | Socket Cap Screw (4) 3/4" Long | K-135    |         |  |          |
| 25             | Dowel Pin (2)                  | K-3485   |         |  |          |
| 26             | Brake and Switch Plate         | 21168    |         |  |          |
| 27             | Dowel Pin                      | 12868    |         |  |          |
| 28             | Socket Cap Screw               | K-151    |         |  |          |

( ) Figures in parentheses indicate quantities of identical parts



Photo 57



# Photo 58

PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig<br>No. | Part Name                                    | SPINDLE     |            | Part Name | Part<br>No. |
|------------|--|-------------|------------|-----------|-------------|
|            |  | Part<br>No. | Fig<br>No. |           |             |
| 1          | Socket Cap Screw                             | K-148       |            |           |             |
| 2          | Depth Stop Cover Plate                       | 21153       |            |           |             |
| 3          | Barrel Lock Screw                            | 7017        |            |           |             |
| 4          | Brass Shoe                                   | 9803        |            |           |             |
| 5          | Lock Screw Handle                            | 12881       |            |           |             |
| 6          | Feed Stop                                    | 15239       |            |           |             |
| 7          | Cutter Spindle Barrel                        | 21146       |            |           |             |
| 8          | Ball Bearing Lock Nut                        | 21147       |            |           |             |
| 9          | Ball Bearing Lock Nut                        | K-1350      |            |           |             |
| 10         | Tang Lock Washer                             | K-95        |            |           |             |
| 11         | Ball Bearing Grease Seal                     | 21149       |            |           |             |
| 12         | Upper Ball Bearing (1 set)                   | KB-3905     |            |           |             |
| 13         | Spindle Bearing Spacer                       | 21150       |            |           |             |
| 14         | Lower Ball Bearing (1 set)                   | KB-6065     |            |           |             |
| 15         | Draw Bar Thrust Collar                       | 21153       |            |           |             |
| 16         | Cutter Spindle                               | 21145       |            |           |             |
| 17         | Draw Bar - Rod and Head<br>(Includes No. 18) | CP-1882     |            |           |             |
| 19         | Spindle Sleeve Spring                        | 8769        |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |

(1) Figures in parentheses indicate quantities of identical parts 2741-K



# Photo 59



# Photo 60

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


Always Give  
Machine Model Number  
and SERIAL NUMBER

|         |  | SPINDLE FEED WORKS |         |                             |          |
|---------|--|--------------------|---------|-----------------------------|----------|
| Fig No. | Part Name  | Part No.           | Fig No. | Part Name                   | Part No. |
| 1       | Head Feed Housing                                  | 21167              | 28      | Spindle Feed Worm           | 21197    |
| 2       | Socket Head Cap Screw (5)                          | K-2027             | 29      | Taper Pin                   | K-477    |
| 3       | Spindle Feed Shaft                                 | 21184              | 30      | Oilite Bearing (2)          | K-2337   |
| 4       | Spacer for Spindle Feed Shaft                      | 7959               | 31      | Hand Wheel Bearing Sleeve   | 21196    |
| 5       | Feed Clutch  | 21186              | 32      | Cone Point Socket Set Screw | K-2633   |
| 6       | Spindle Feed Worm Wheel                            | 21187              | 33      | Micrometer Dial             | 9236     |
| 7       | Needle Bearing (2)                                 | 1602               | 34      | Taper Pin                   | K-479    |
| 8       | Bearing Retaining Sleeve                           | 21188              | 35      | Taper Pin                   | K-471    |
| 9       | Spindle Feed Pinion                                | 7961               | 36      | Hand Crank                  | 6656     |
| 10      | Snap Ring  | K-6111             | 37      | Dial Collar                 | 21279    |
| 11      | Bearing Retaining Sleeve                           | 21189              | 38      | Thumb Screw                 | 4987     |
| 12      | Socket Cap Screw                                   | K-132              |         |                             |          |
| 13      | Spindle Feed Lever                                 | 8659               |         |                             |          |
| 14      | Socket Set Screw (2) one 1" long and one 5/8" long | K-2706             |         |                             |          |
| 15      | Socket Set Screw                                   | K-189              |         |                             |          |
| 16      | Taper Pin  | K-486              |         |                             |          |
| 17      | Dowel Pin  | 12840              |         |                             |          |
| 18      | Oilite Bearing                                     | K-2038             |         |                             |          |
| 19      | Shifter Handle                                     | 12875              |         |                             |          |
| 20      | Feed Clutch Shifter                                | 21219              |         |                             |          |
| 21      | Steel Ball   | K-76               |         |                             |          |
| 22      | Spring   | 7718               |         |                             |          |
| 23      | Socket Set Screw                                   | K-2009             |         |                             |          |
| 24      | Woodruff Key                                       | K-5436             |         |                             |          |
| 25      | Taper Pin  | K-484              |         |                             |          |
| 26      | Socket Set Screw                                   | K-3628             |         |                             |          |
| 26a     | Brass Plug for Above Not Shown                     | 11994              |         |                             |          |
| 27      | Dog Point Socket Set Screw                         | K-4076             |         |                             |          |

( ) Figures in parentheses indicate quantities of identical parts

2743-G

# Photo 61



# Photo 62

## PARTS LIST - - GORTON 1-22 MASTERWIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

### SPINDLE POWER FEED


Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig No. | Part Name                 | Part No. | Fig No. | Part Name                  | Part No. |
|---------|---------------------------|----------|---------|----------------------------|----------|
| 1       | Transmission Cover        | 21156    | 28      | Spring Retaining Ring      | 21252    |
| 2       | Bevco Pulley              | 21243    | 29      | Slip Coupling              | 21230    |
| 3       | Socket Set Screw          | K-2529   | 30      | Gilite Thrust Washer       | K-3561   |
| 4       | Transmission              | K-6148   | 31      | Slip Clutch Housing        | 21247    |
| 5       | Transmission Drive Belt   | K-5976   | 32      | Roll Pin                   | K-5974   |
| 6       | Feed Drive Pulley         | 21242    | 33      | Slip Coupling Worn         | 21157    |
| 7       | Socket Set Screw N" Long  | K-2006   | 34      | Clutch Worm Wheel          | 21239    |
| 8       | Not Used                  |          | 35      | Dowel Pin                  | 12864    |
| 9       | Dowel Pin (2)             | K-6124   | 36      | Worm Gear Spacer           | 21248    |
| 10      | Socket Cap Screw (2)      | K-1618   | 37      | Clutch                     | 21238    |
| 11      | Transmission Bracket      | 21244    | 38      | Woodruff Key               | K-4495   |
| 12      | Washer                    | 13129    | 39      | Down Feed Shifter Fork     | 21240    |
| 13      | Hex Head Cap Screw        | K-267    | 40      | Socket Set Screw           | K-2529   |
| 14      | Socket Set Screw (2)      | K-4702   | 41      | Roll Pin                   | K-5944   |
| 15      | Clutch Drive Gear         | 21234    | 42      | Clutch Shifter Shaft       | 21241    |
| 16      | Clutch Drives Gear        | 21235    | 43      | Shifter Handle             | 12875    |
| 17      | Oilite Bearing            | K-2038   | 44      | Down Feed Clutch Shifter   | 21254    |
| 18      | Roll Pin                  | K-5440   | 45      | Dog Point Socket Set Screw | K-6177   |
| 19      | Feed Gear Housing         | 21253    | 46      | Spring                     | 7710     |
| 20      | Socket Cap Screw (5)      | K-2027   | 47      | Steel Ball                 | K-76     |
| 21      | Dowel Pin (2)             | K-3808   | 48      | Socket Set Screw           | K-3620   |
| 21a     | Plug (2) Not Shown        | 17963    | 48a     | Brass Plug Not Shown       | 11994    |
| 22      | Button Head Screw (3)     | K-6131   |         |                            |          |
| 23      | Gear Shaft                | 21231    |         |                            |          |
| 24      | Oilite Flange Bearing (2) | K-4004   |         |                            |          |
| 25      | Socket Set Screw (2)      | K-187    |         |                            |          |
| 26      | Gear Shaft Bushing        | 21233    |         |                            |          |
| 27      | Slip Spring (4)           | 21253    |         |                            |          |

( ) Figures in parentheses indicate quantities of identical parts

2741-II

# Photo 63



# Photo 64

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

### KNEE


Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig No. | Part Name                            | Part No. | Fig No. | Part Name | Part No. |
|---------|--------------------------------------|----------|---------|-----------|----------|
| 1       | Handle                               | K-542    |         |           |          |
| 2       | Hell Pin                             | 21075    |         |           |          |
| 3       | Hand Wheel                           | 21071    |         |           |          |
| 4       | Dial Collar                          | 21069    |         |           |          |
| 5       | Thumb Screw                          | 21136    |         |           |          |
| 6       | Micrometer Dial                      | 21118    |         |           |          |
| 7       | Lock Nut                             | K-2478   |         |           |          |
| 8       | Lock Washer                          | K-6988   |         |           |          |
| 9       | Ball Bearing - Front                 | KB-6230  |         |           |          |
| 9a      | Bearing Pre-Load Washer<br>Nut Shows | K-6235   |         |           |          |
| 10      | Ball Bearing - Rear                  | KB-2527  |         |           |          |
| 11      | Socket Head Cap Screw (3)            | K-135    |         |           |          |
| 12      | Cross Feed Bearing Housing           | 21058    |         |           |          |
| 13      | Cross Feed Screw                     | 21069    |         |           |          |
| 14      | Knee                                 | 21052    |         |           |          |
| 15      | Hell Pin                             | K-5982   |         |           |          |
| 16      | Knee Clamping Lever                  | 21059    |         |           |          |
| 17      | Knee Clamping Hub                    | 21061    |         |           |          |
| 18      | Knee Clamping Shaft                  | 21065    |         |           |          |
| 19      | Not Used                             |          |         |           |          |
| 20      | Gib Adjusting Screw (2)              | 6296     |         |           |          |
| 21      | Knee Gib                             | 21073    |         |           |          |
| 22      | Oil Cup                              | K-2132   |         |           |          |
| 23      | Socket Set Screw                     | K-2009   |         |           |          |
| 24      | Knee Gib Lock                        | 21066    |         |           |          |
|         |                                      |          |         |           |          |
|         |                                      |          |         |           |          |
|         |                                      |          |         |           |          |
|         |                                      |          |         |           |          |

( ) Figures in parentheses indicate quantities of identical parts 2741-F



# Photo 65



# Photo 66

## PARTS LIST - - GORTON 1-22 WASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts.

Always Give  
Machine Model Number  
and SERIAL NUMBER


### KNEE ELEVATE COMPONENTS

| Fig. No.      | Part Name                                 | Part No.                  | Fig. No. | Part Name                    | Part No. |
|---------------|---|---------------------------|----------|------------------------------|----------|
| 1             | Socket Cap Screw (3)                      | K-2505                    | 29       | Lock Nut                     | K-2478   |
| 2             | Elevate Gear Bearing Housing              | 21053                     | 30       | Elevate Micrometer Dial      | 21042    |
| 3             | Lock Nut                                  | K-2478                    | 31       | Thumb Screw                  | 21126    |
| 4             | Lock Washer                               | K-5988                    | 32       | Roll Pin                     | K-5563   |
| 5             | Ball Bearing                              | NB-5985                   | 33       | Dial Clutch                  | 21121    |
| 6             | Snap Ring                                 | K-5987                    | 34       | Elevate Crank Clutch         | 21123    |
| 7             | Elevate Gear                              | 21063                     | 35       | Socket Set Screw - Dog Point | K-1379   |
| 8             | Elevate Screw                             | 21070                     | 36       | Elevate Crank                | 21072    |
| 9             | Socket Cap Screw (2)                      | K-175                     | 37       | Crank Handle                 | K-542    |
| 10            | Elevate Bracket <i>ENJF</i>               | <del>21064</del><br>21064 |          |                              |          |
| <del>11</del> | <del>Elevate Nut</del>                    | <del>21065</del>          |          |                              |          |
| 12            | Roll Pin                                  | K-5981                    |          |                              |          |
| 13            | Oil Cap                                   | K-2132                    |          |                              |          |
| 14            | Hydro Key                                 | K-4505                    |          |                              |          |
| 15            | Elevate Hand Crank Shaft                  | 21068                     |          |                              |          |
| 16            | Elevate Drive Gear                        | 21064                     |          |                              |          |
| 17            | Roll Pin                                  | K-5983                    |          |                              |          |
| 18            | Elevate Drive Gear Spacer                 | 21074                     |          |                              |          |
| 19            | Ball Bearing                              | NB-3418                   |          |                              |          |
| 20            | Elevate Bearing Plate                     | 22164                     |          |                              |          |
| 21            | Not Used                                  |                           |          |                              |          |
| 22            | Socket Cap Screw (3)                      | K-145                     |          |                              |          |
| 23            | Not Used                                  |                           |          |                              |          |
| 24            | Ball Bearing - Inner                      | NB-2527                   |          |                              |          |
| 24a           | Ball Bearing Pre-load Washer<br>Not Shown | K-6225                    |          |                              |          |
| 25            | Ball Bearing - Outer                      | NB-6230                   |          |                              |          |
| 26            | Socket Cap Screw (3)                      | K-135                     |          |                              |          |
| 27            | Bearing Plate                             | 21119                     |          |                              |          |
| 28            | Lock Washer                               | K-5988                    |          |                              |          |

( ) Figures in parentheses indicate quantities of identical parts

2741-C

# Photo 67



# Photo 68

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

Always Give  
Machine Model Number  
and SERIAL NUMBER


### SADDLE COMPONENTS

| Fig. No. | Part Name   | Part No. | Fig. No. | Part Name                          | Part No. |
|----------|---|----------|----------|------------------------------------|----------|
| 1        | Button Head Screw (2)                             | K-6365   | 30       | Socket Head Cap Screw (4)          | K-153    |
| 2        | Oil Metering Unit (2) 3-B Size                    | K-5993   | 31       | Cross Feed Nut Housing             | 21082    |
| 3        | Not Used  |          | 32       | Oil Metering Unit 1-B Size         | K-5996   |
| 4        | Adjustable Table Nut                              | 21092    | 33       | Dowel Pin (2)                      | K-3650   |
| 5        | Fixed Table Nut Key                               | 21111    | 34       | Oil Metering Unit (2) 1-B Size     | K-5996   |
| 6        | Fixed Table Nut                                   | 21091    | 35       | Not Used                           |          |
| 7        | Gib Adjusting Screw (2)                           | 6296     | 36       | Saddle Feed Nut                    | 21090    |
| 8        | Oil Line Sleeve (2)                               | K-4522   | 36a      | Dowel Pin Not Shown                | K-6000   |
| 9        | Oil Line Nut (2)                                  | K-4604   | 37       | Ball Bearing Lock Nut              | K-87     |
| 10       | Oil Fitting (2)                                   | K-5440   | 38       | Oil Metering Unit 3-B Size         | K-5993   |
| 11       | Not Used  |          | 39       | Oil Metering Unit 1-B Size         | K-5996   |
| 12       | Saddle Gib  | 21096    | 40       | Table Clamping Screw               | 21084    |
| 13       | Saddle  | 21089    | 41       | Taper Pin                          | K-470    |
| 14       | Hand Feed Oil Line                                | 21357    | 42       | Table Clamping Lever               | 16954    |
| 15       | Not Used  |          | 43       | Table Feed Stop                    | 21113    |
| 16       | Oil Sight Window                                  | K-5992   | 44       | Hex Head Cap Screw                 | K-6188   |
| 17       | Oil Filler Plug                                   | 18357    | 45       | Dowel Pin                          | K-6004   |
| 18       | Roll Pin  | K-5982   | 46       | Screw Dog for Table Clamping Screw | 14827    |
| 19       | Saddle Clamping Lever                             | 21059    |          |                                    |          |
| 20       | Saddle Gib Clamp Screw                            | 21110    |          |                                    |          |
| 21       | Socket Head Cap Screw (4)                         | K-1618   |          |                                    |          |
| 22       | Gib Clamp Rod                                     | 21109    |          |                                    |          |
| 23       | One-Shot Lubrication Pump                         | K-5991   |          |                                    |          |
| 24       | Hex Head Cap Screw (8)                            | K-5999   |          |                                    |          |
| 25       | Guide Plate (2)                                   | 21088    |          |                                    |          |
| 26       | Guide Plate Spacer (2)                            | 21087    |          |                                    |          |
| 27       | Pipe Plug (2)                                     | K-406    |          |                                    |          |
| 28       | Gib Adjusting Screw (2)                           | 6296     |          |                                    |          |
| 29       | Table Nut Adapter (Not on Early Models) Not Shown | 21229    |          |                                    |          |

( ) Figures in parentheses indicate quantities of identical parts

2741-B

# Photo 69



# Photo 70

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts.


Always Give  
Machine Model Number  
and SERIAL NUMBER

### TABLE COMPONENTS

| Fig. No. | Part Name                     | Part No. | Fig. No. | Part Name | Part No. |
|----------|-------------------------------|----------|----------|-----------|----------|
| 1        | Round Head Machine Screw (2)  | K-394    |          |           |          |
| 2        | Coolant Screen Cover          | 21128    |          |           |          |
| 3        | Coolant Screen                | 21127    |          |           |          |
| 4        | Coolant Cover Knob            | 14970    |          |           |          |
| 4a       | Pipe Plug                     | K-414    |          |           |          |
| 5        | Socket Cap Screw (7)          | K-813    |          |           |          |
| 6        | Dowel Pin (4)                 | K-4627   |          |           |          |
| 7        | Left Hand Table End Bracket   | 21117    |          |           |          |
| 8        | Table Dog T-Slot Screw (2)    | 18883    |          |           |          |
| 9        | T-Slot Nut (2)                | 21130    |          |           |          |
| 10       | Adjustable Stop (2)           | 21129    |          |           |          |
| 11       | Socket Head Cap Screw (2)     | K-141    |          |           |          |
| 12       | Machine Table                 | 21115    |          |           |          |
| 13       | Table Screw                   | 21108    |          |           |          |
| 14       | Right Hand Table End Bracket  | 21116    |          |           |          |
| 15       | Table Screw Dial (2)          | 21118    |          |           |          |
| 16       | Thumb Screw (2)               | 21126    |          |           |          |
| 17       | Bell Bearing Lock Nut (2)     | K-2478   |          |           |          |
| 18       | Bell Bearing Lock Washer (2)  | K-5968   |          |           |          |
| 19       | Bell Bearing - Left End       | KB-2527  |          |           |          |
| 20       | Snap Ring                     | K-4591   |          |           |          |
| 21       | Bell Bearing-Inner; Right End | KB-2527  |          |           |          |
| 22       | Pre-Load Washer               | K-6235   |          |           |          |
| 23       | Bell Bearing-Outer; Right End | KB-6230  |          |           |          |
| 24       | Bearing Plate                 | 21119    |          |           |          |
| 25       | Socket Cap Screw (3)          | K-135    |          |           |          |
| 26       | Hand Wheel (2)                | 21125    |          |           |          |
| 27       | Roll Pin (2)                  | K-5984   |          |           |          |
| 28       | Handle (2)                    | K-542    |          |           |          |

( ) Figures in parentheses indicate quantities of identical parts

# Photo 71



# Photo 72

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

Always Give  
Machine Model Number  
and SERIAL NUMBER

### MANUAL TRACER HEAD 1018-1


| Fig No. | Part Name                      | Part No. | Fig No. | Part Name               | Part No. |
|---------|--------------------------------|----------|---------|-------------------------|----------|
| 1       | Tracer Spindle Head            | 13823    | 28      | Drill Rod Pin           | 12636    |
| 2       | Hex Head Cap Screw (4)         | 1730     | 29      | Drill Rod Pin (2)       | 12728    |
| 3       | Tracer Spindle Sleeve          | 17612    | 30      | Draw Bar and Hand Wheel | CP-1783  |
| 4       | Screw                          | 3271     | 31      | Spring Retainer Nut     | 8615     |
| 4a      | Tracer Spindle Sleeve Bushing  | 9211     | 32      | Socket Set Screw        | K-190    |
| 5       | Tracer Sleeve Key              | 8745     | 33      | Taper Pin (2)           | K-486    |
| 5a      | Tracer Sleeve Spring           | 9212     | 34      | Tracer Spindle          | 9209     |
| 6       | Socket Cap Screw               | K-157    | 35      | Spindle Thrust Spring   | 8816     |
| 7       | Oil Cup                        | K-515    | 36      | Sleeve Washer           | 9213     |
| 8       | Oil Cup                        | K-519    | 37      | Drill Rod Pin           | 12008    |
| 9       | Socket Cap Screw (2)           | K-151    | 38      | Tracer Spindle Collet   | 14877    |
| 10      | Feed Shaft Coupling            | 8737     |         |                         |          |
| 11      | Spindle Adjusting Nut          | 8806     |         |                         |          |
| 12      | Micrometer Dial                | 8812     |         |                         |          |
| 13      | Thumb Screw                    | 4987     |         |                         |          |
| 14      | Lock Screw Handle              | 12926    |         |                         |          |
| 15      | Lock Screw                     | 8807     |         |                         |          |
| 16      | Socket Cap Screw               | K-152    |         |                         |          |
| 17      | Spindle Adjusting Nut Bearing  | 8805     |         |                         |          |
| 18      | Thrust Collar                  | 8813     |         |                         |          |
| 19      | Thrust Nut                     | 8814     |         |                         |          |
| 20      | Collar                         | 9219     |         |                         |          |
| 21      | Tracer Feed Pinion             | 7961     |         |                         |          |
| 22      | Tracer Spindle Feed Shaft      | 13825    |         |                         |          |
| 23      | Feed Shaft Bearing             | 14185    |         |                         |          |
| 24      | Adapter Washer                 | 13827    |         |                         |          |
| 25      | Counter Balance Spring         | 8740     |         |                         |          |
| 26      | Counter Balance Spring Housing | 8741     |         |                         |          |
| 27      | Socket Cap Screw               | K-152    |         |                         |          |

() Figures in parentheses indicate quantities of identical parts

2741-AA



# Photo 73



# Photo 74

## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


### DUPLICATOR TABLE TOP

Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig<br>No. | Part Name   | Part<br>No. | Fig<br>No. | Part Name | Part<br>No. |
|------------|---|-------------|------------|-----------|-------------|
| 1          | Saddle Apron - Rear                                       | 15117       |            |           |             |
| 2          | Stud Hole Plug (16)                                       | 9093        |            |           |             |
| 3          | Slotted Pipe Plug (4)                                     | K-407       |            |           |             |
| 4          | Duplicator Table  | CP-231      |            |           |             |
| 5          | Table Lock Screw (2)                                      | 8652        |            |           |             |
| 6          | Table Lock Screw Washer -<br>Left Hand                    | 10997       |            |           |             |
| 7          | Table Lock Screw Washer -<br>Right Hand                   | 8653        |            |           |             |
| 8          | Instruction Plate   | K-6164      |            |           |             |
| 9          | Table Nameplate   | K-6165      |            |           |             |
| 9a         | Drive Pin for Instruction and<br>Nameplates (8) Not Shown |             |            |           |             |
| 10         | Offset Micrometer Screw and<br>Holder                     | CP-139      |            |           |             |
| 11         | Clamp Screw Washer  | 9274        |            |           |             |
| 12         | Clamp Screw   | 10996       |            |           |             |
| 13         | Saddle Apron - Front                                      | 9317        |            |           |             |
| 14         | Master Table  | 8660        |            |           |             |
| 15         | Master Table Base   | 8661        |            |           |             |
| 16         | Micrometer Screw and Holder                               | CP-140      |            |           |             |
| 17         | Master Table Clamp Screw (2)                              | 8946        |            |           |             |
| 18         | T-Slot Nut (2)  | 11897       |            |           |             |
| 19         | Clamping Plate (2)  | 8721        |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |
|            |   |             |            |           |             |

( ) Figures in parentheses indicate quantities of identical parts 2831-D

# Photo 75



# Photo 76

PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

Always Give  
Machine Model Number  
and SERIAL NUMBER


DUPLICATOR TABLE - BOTTOM

| Fig<br>No. | Part Name  | Part<br>No. | Fig<br>No. | Part Name | Part<br>No. |
|------------|--|-------------|------------|-----------|-------------|
| 1          | Balls for Ball Bearing Slides<br>(336) for All Ball Tracks | RR-77       |            |           |             |
| 2          | Chip Aprons - Front and Rear                               | 11233       |            |           |             |
| 3          | Screw for Apron Holders (8)                                | 3271        |            |           |             |
| 4          | Apron Holder (2)   | 9266        |            |           |             |
| 5          | Hex Head Nut (2)   | 3335        |            |           |             |
| 6          | Apron Spring Screw (2)                                     | 9307        |            |           |             |
| 7          | Socket Set Screw   | K-4076      |            |           |             |
| 8          | Apron Spring   | 9616        |            |           |             |
| 9          | Felt Seal (2)  | 11775       |            |           |             |
| 10         | Ball Track Cap Screw (20)                                  | 8723        |            |           |             |
| 11         | Ball Track (2)   | 9256        |            |           |             |
| 12         | Duplicator Table with<br>Brake Plate                       | CP-231      |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |
|            |  |             |            |           |             |

( ) Figures in parentheses indicate quantities of identical parts      2831-A



# Photo 77



## PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts


Always Give  
Machine Model Number  
and SERIAL NUMBER

| Fig. No. | Part Name                               | Part No. | Fig. No. | Part Name | Part No. |
|----------|---|----------|----------|-----------|----------|
| 1        | Felt Seal (2)                           | 11778    |          |           |          |
| 2        | Bell Track (2)                          | 9255     |          |           |          |
| 3        | Bell Bearing Retainer Positive Side (2) | CP-1609  |          |           |          |
| 3a       | Bell Bearing Retainer Gib Side (2)      | CP-1608  |          |           |          |
| 4        | Felt Seal (4)                           | 11576    |          |           |          |
| 5        | Bell Bearing Retainer Cap Screw (8)     | 14763    |          |           |          |
| 6        | Washer for Above (8)                    | K-459    |          |           |          |
| 7        | Bell Track Cap Screw (10)               | 8723     |          |           |          |
| 8        | Oil Cap (4)                             | K-515    |          |           |          |
| 9        | Washer                                  | 9274     |          |           |          |
| 10       | Clamp Screw                             | 9273     |          |           |          |
| 11       | U-Clamp                                 | 9272     |          |           |          |
| 12       | Duplicator Table Saddle - Top           | 9251     |          |           |          |
| 13       | Saddle Gib                              | 9419     |          |           |          |
| 14       | Gib Adjusting Screw (2)                 | 19155    |          |           |          |
| 15       | Lock Nut (2)                            | K-5703   |          |           |          |
| 16       | Lock Washer (2)                         | K-5704   |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |
|          |   |          |          |           |          |

( ) Figures in parentheses indicate quantities of identical parts

2831-C


# Photo 79







# Photo 81



# Photo 82

## PARTS LIST - - GORTON 1-22 MASTERMIL


Order by Gorton Part Number  
and Name Always Use Genuine  
Gorton Parts

Always Give  
Machine Model Number  
and SERIAL NUMBER

| DUPLICATOR TABLE BASE-TOP |  |          |          |           |          |
|---------------------------|--|----------|----------|-----------|----------|
| Fig. No.                  | Part Name                                | Part No. | Fig. No. | Part Name | Part No. |
| 1                         | Table Lock Adjusting Screw (2)           | 8722     |          |           |          |
| 2                         | Washer for above (2)                     | 9392     |          |           |          |
| 3                         | Table Lock Adjusting Screw Nut (2)       | 8759     |          |           |          |
| 4                         | Brake Spring                             | 9316     |          |           |          |
| 5                         | Brake Stud                               | 9312     |          |           |          |
| 6                         | Brake Shoe                               | CP-56    |          |           |          |
| 7                         | Brake Adjusting Nut                      | 9313     |          |           |          |
| 8                         | Table Stop Pin                           | 8651     |          |           |          |
| 9                         | Ball Bearing Retainer - Cap Screw (8)    | 14763    |          |           |          |
| 10                        | Washer (8)                               | K-459    |          |           |          |
| 11                        | Felt Seal (4)                            | 11576    |          |           |          |
| 12                        | Ball Bearing Retainer Gib Side (2)       | CP-1608  |          |           |          |
| 12a                       | Ball Bearing Retainer - Pouline Side (2) | CP-1609  |          |           |          |
| 13                        | Felt Seal (2)                            | 11778    |          |           |          |
| 14                        | Gib Adjusting Screw (2)                  | 19155    |          |           |          |
| 15                        | Lock Washer (2)                          | K-5704   |          |           |          |
| 16                        | Lock Nut (2)                             | K-5703   |          |           |          |
| 17                        | Gib                                      | 9419     |          |           |          |
| 18                        | Ball Race (2)                            | 9255     |          |           |          |
| 19                        | Ball Track Cap Screw (16)                | 8723     |          |           |          |
| 20                        | Duplicator Table Base-Top                | 9250     |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |
|                           |  |          |          |           |          |

( ) Figures in parentheses indicate quantities of identical parts 2031-B  
79

# Photo 83



# Photo 84

PARTS LIST - - GORTON 1-22 MASTERMIL

Order by Gorton Part Number  
and Name. Always Use Genuine  
Gorton Parts

Always Give  
Machine Model Number  
and SERIAL NUMBER

TABLE LEVER ASSEMBLY

| Fig No. | Part Name                   | Part No. | Fig No. | Part Name | Part No. |
|---------|-----------------------------|----------|---------|-----------|----------|
| 1       | Upper Lever Support Bracket | 21717    |         |           |          |
| 2       | Socket Cap Screw (8)        | K-161    |         |           |          |
| 3       | Lower Lever Support Bracket | 22005    |         |           |          |
| 4       | Chip Shield (2)             | 22077    |         |           |          |
| 5       | Socket Set Screw (2)        | K-187    |         |           |          |
| 6       | Socket Cap Screw            | K-148    |         |           |          |
| 7       | Grass Fitting (2)           | K-6371   |         |           |          |
| 8       | Snap Ring (4)               | K-6149   |         |           |          |
| 9       | Uni-Ball Bearing (2)        | K-6150   |         |           |          |
| 10      | Lever Sleeve                | 22006    |         |           |          |
| 11      | Plunger Spring              | 9265     |         |           |          |
| 12      | Lever Plunger               | 22007    |         |           |          |
| 13      | Lever Rod                   | 21720    |         |           |          |
| 14      | Lever Extension             | 21712    |         |           |          |
| 15      | Lever Rod Handle            | 8954     |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |
|         |                             |          |         |           |          |

( ) Figures in parentheses indicate quantities of identical parts 2741-X



INSTRUCTIONS FOR INSTALLING 1235-1

INFINITELY VARIABLE SPINDLE DOWN FEED

ASSEMBLY ON GORTON MASTERMIL 1-22S

(Refer to Drawings 2755-A and 2755 Attached)


1. Remove old cover plate at left side of head.
2. Remove spindle motor (do not injure wiring or cable).
3. Insert small pulley into bottom of motor pulley and lock in place with set screw.
4. Remove "A" assembly from power down feed unit. First remove hex-head clamping screw from bottom of flange which is part of casting 21251. Next, turn "A" assembly counter-clockwise to stop and lift up (bayonet lock).
5. Remove set screw "B" in left side of spindle housing so that shaft assembly "C" can be extracted by pulling out.
6. Fit new Woodruff key and clutch "D" to shaft "C".
7. Press new pin 12664 into shaft "C" where indicated and file until clutch 21236 slides over it freely.
8. In sliding new spacing washer 21248 over new pin 12664, be sure it is a sliding fit and spacer butts against shoulder of shaft. Now slide new worm wheel 21239 on shaft (running fit).
9. Press "E" (new bushing) into head casting as shown (if not already in place).
10. Now, remove shaft assembly "F" from new down feed unit by loosening two set screws K-187 so that shaft "F" can be tried in bushing "E" (running fit).
11. Remove worm wheel 21239, spacer 21248 and clutch 21236 from hand feed shaft. Replace shaft in head assembly and re-install clutch, spacer and worm wheel when end of shaft clears down feed gear attached to down feed shaft.

# Photo 86

12. When above is accomplished, set screw "B" should fit exactly into countersunk hole in shaft "C" so that entire shaft assembly turns freely. It may be necessary to add an extra spacer or to remove some metal from spacer 21248 in order to assure a perfect fit of set screw "B". There should be no more than .002" play in worm wheel 21239.
13. Position yoke 21240 (held with set screw) so final alignment with clutch 21236 can be made by placing casting 21251 including yoke on machine. Position yoke 21240 by sighting through opening left by removing assembly "A". Use lever 12875 for trial engagements of clutch.
14. Remove casting 21251 assembly and pin yoke in place with roll pin K-5944.
15. Reassemble all components and grease. Attach belt to small pulley at bottom of motor shaft. Insert hex-head clamping screw in bottom of flange (part of casting 21251) adjust belt for proper tension and tighten hex-head clamping screw.
16. Tap entire assembly lightly while running to align for doweling.
17. When operating freely, dowel for positive location.

George Gorton Machine Co. Racine, Wisconsin, U. S. A.

# Photo 87



2753-A

Photo 88








Photo 89



# Photo 90



# Photo 91

1-22 VARIABLE SPEED MILLING HEAD--PART NO.'S

Form 3250 (pgs. 1 & 2) attached - Drg. T1494-1

Used on Machines Beginning with Serial Numbers:

|                              |           |
|------------------------------|-----------|
| 1-22 Hand Feed               | S/N 44402 |
| 1-22 Power Feed              | S/N 44320 |
| 1-22 with Horizontal Spindle | S/N 42525 |
| 1-22 Trace-Master            | S/N 38699 |

Photo 92





Photo 93



# Photo 94

## GUARANTY

The GEORGE GORTON MACHINE CO. agrees to remedy any condition caused by faulty workmanship or materials in products of its manufacture, by repairing and/or replacing defective parts up to one year from date of shipment direct to customer or to dealer for re-shipment to customer, provided that the machine, tooling or other equipment covered by this guaranty is still in the possession of the original purchaser and has not (in the opinion of the George Gorton Machine Co.) been abused or misused. This guaranty supersedes and replaces any and all other guaranties or warranties, either expressed or implied, and is limited by the foregoing statement.

GEORGE GORTON MACHINE CO.  
RACINE, WISCONSIN