

Photo 1




Photo 2




Photo 3

OPERATOR'S MANUAL

NO. 3227

2-30 VERTICAL MILL

This Is An Operator's Manual Only. For installation, Maintenance Procedure and Replacement Parts Refer To Manual No. 3229.

This Manual Contains Operating Instructions For The Gorton Model 2-30 Vertical Milling Machine.

The machine to which this manual applies has been carefully assembled, inspected and test-run under maximum load at the Gorton factory. It is in satisfactory operating condition. Routine operations and adjustments are explained herein, but the manufacturer will not be held responsible for satisfactory operation if unauthorized modifications, alterations or major repairs are attempted without specific instructions from the factory. One of these manuals is furnished with each machine. Additional copies may be purchased direct from the George Gorton Machine Co. at \$2.50 each.

GEORGE GORTON MACHINE CO.
RACINE, WISCONSIN, U.S.A.

The right is reserved to improve, change, modify or discontinue any Gorton machine, attachment or accessory without obligation to make such improvement, change or modification or equipment previously sold or on order.

Patent Notice: The machines and attachments to which these instructions apply are protected by issued and pending United States and foreign patents.

Photo 4




Photo 5





Photo 6



1. Spindle Feed Lever
2. Spindle Brake Lever
3. Spindle Start-Stop High-Low Motor Speed Selector
4. Micrometer Depth Slip
5. Quill Locking Lever
6. Ram Clamping Bolts

7. Longitudinal Table Handwheel
8. Cross Feed Handwheel
9. Vertical Elevate Handwheel
10. Power Elevate Lever
11. Saddle Clamping Levers
12. Fused Disconnect Switch

1. M
2. T
3. S
4. R
5. M
6. M
7. S

Photo 7





Photo 8



SPINDLE/QUILL DOWNFEED

HAND FEED

This machine is equipped with a vertical feed lever (1) on the left side of the head for fast hand positioning. A micrometer handfeed crank (2) is located on the left side with dial graduated in .100" per revolution for positioning of the spindle/quill within the 3-1/2" total travel. A precision micrometer depth stop (3) is mounted on the front of the head housing. This depth stop has a graduated scale and micrometer dial. The dial can be locked in any position by tightening the knurled knob on the center front of the depth stop bracket.

To move spindle by lever (1) unclamp quill lock (4) by pushing to rear. Place operating lever (5) to left position and move spindle to desired position against depth stop (3) with lever. Clamp by pulling lever (6) toward operator.

To move spindle by micrometer handfeed crank, quill lock (4) is pushed to rear to unlock, and operating lever (5) is positioned at right.

NOTE

It may be necessary to move quill slightly with lever (1) to engage clutch.

Quill can then be positioned with micrometer hand crank to desired position. Clamp by pulling lever (6) toward operator.

POWER FEED

When machine is equipped with infinitely variable power spindle downfeed, a feed rate selector (7), .250" to 3" per minute and direction selector (8) are located on the control panel, and downfeed clutch lever (6) is located beneath the gear box.

To engage power feed, the hand feed micrometer crank is engaged (steps outlined under Hand Feed) and clutch lever (6) is engaged (back position). The desired downfeed rate is selected (dial 7) and

Photo 9

feed is engaged by moving selector (7) to "down" position. Depth is established by micrometer depth stop (8). Upon reaching depth stop, feed motor continues to drive through overriding clutch (clicking noise) until direction is reversed.

CONTROL OPTIONS

NOTE

Feed rate can be changed in the cut by moving dial (6). Feed direction can be changed or stopped at any time by resetting direction selector (7). Disengaging clutch (8) only permits move-

ment of quill by hand crank (2). Disengaging lever (5) only permits movement of quill by lever (3). It is suggested that operator check out these options of control prior to actual boring operations.

INTERLOCK NOTE

Machines equipped with power down-feed have an electrical interlock to table drive to prevent power movement of table while using spindle power downfeed. Feed rate selector (6) MUST BE turned to "off" position (clicking noise) to again use power table feeds.

INSERTING COLLETS/ADAPTERS

This machine is furnished with No. 10 B & S or No. 40 N. S. spindle taper. Both tapers utilize draw bars to hold collets, cutters or adapters. The No. 10 B & S spindle draw bar is inserted into the spindle from the top and the thrust collar threaded onto spindle (left-hand thread) with draw bar square end protruding. The thrust collar will remain in place unless draw bar must be removed.

CAUTION

Be sure inside of spindle nose and shank of adapter are clean and dry before assembling.

Insert adapter into spindle nose and thread draw bar into adapter. Insert cutter or tool into adapter. Draw up by turning draw bar square head nut with wrench (while spindle brake lever is set) until adapter is tight in spindle. Now back off with wrench, then snug up. This is to insure relieving partial tension on draw bar so the adapter will not become locked in spindle taper through temperature change of spindle at high R. P. M.

To loosen cutter, set the spindle brake lever

and apply wrench to square head nut; turn counterclockwise—tapping wrench is permissible. Initial movement loosens drawbar hold on adapter; continued movement forces adapter out of spindle nose. **DO NOT USE HAMMER ON TOP OF DRAW BAR.**

If adapter is to be used to accommodate Gorton collets, the thrust collar and draw bar are removed and draw bar with knurled handwheel is used. Insert adapter into spindle taper securely. Next, insert collet/cutter and draw up tight by turning knurled handwheel draw bar clockwise with square wrench. To remove collet and adapter, set brake lever, release knurled handwheel draw bar, remove collet, remove draw bar, insert adapter draw bar, install thrust collar, apply wrench to square head of draw bar to force adapter from spindle nose.

When inserting adapter into No. 40 N. S. spindle nose, be sure that driving keys of spindle do not "hang up". The adapter must mate with the key drive of the spindle and be drawn securely into the spindle taper through threading of the draw bar into the adapter.

FLOOD COOLANT SYSTEM

The flood coolant system is self-contained within the machine. The pump reservoir with is located within the rear lower column with access provided through the remountable plate. The coolant return line is connected to the left table bracket and to the reservoir. A screen is provided in the table to collect chips and foreign material. The supply line has a flexible nozzle and shut-off valve.

The selector switch controlling the pump motor is located on the front surface of the machine electrical cabinet. The pump motor is electrically interlocked with the spindle motor. Stopping the

spindle motor will cause the pump motor to stop.

The shut-off on the flexible nozzle should be in "off position" when starting spindle and prior to stopping spindle. "Prime" will be lost if pump motor is stopped prior to shutting off flow at nozzle.

Keep return line open through removal of material over table screen and from table channels. Clean screen periodically.

Remove reservoir from column periodically and inspect for presence of foreign material. Remove if present to prevent damage to pump.

Photo 10

SPRAY MIST COOLANT SYSTEM

The spray mist coolant system is self-contained with exception of attachment of plant air line to reservoir unit. The unit is mounted to the machine column with air and coolant lines extending to a flexible nozzle with magnetic holder. A thumb screw nozzle control on the nozzle controls the volume of coolant.

The plant air line connects to the left side of the unit. Pressure should not exceed 125 lbs. The air and coolant lines connect to the right side of the unit. A slotted screw, under the screw nut on the top left of the unit can be turned to regulate air pressure to the nozzle. A gage indicates air pressure.

The selector switch controlling the unit is located on the front surface of the machine electrical cabinet. The flow of air/coolant is electrically interlocked with the spindle motor. Stopping the spindle motor will halt the flow of air/coolant.

OPERATION

Fill reservoir with water soluble oil to cool-

TO PLACE IN OPERATION — SPINDLE

CAUTION

Before starting spindle, be certain that draw bar is removed or is firmly engaged in adapter, collet or cutter.

Be certain that drive V-belt (10) is engaged

TO CHANGE SPEEDS — SPINDLE

The fourteen speeds of the milling head are obtained through a two-speed motor driving stepped pulleys by means of a single V-belt. Change from

TO CHANGE SPEEDS — MOTOR

To change motor speeds (belt drive remains unchanged), the HI-LO selector ring (1) on start button (2) is rotated to desired position, stop button (3) is actuated and start button (2) is actuated.

NOTE

The sequence of depressing the stop

and manufacturer's specifications and consistency insure non-rust and non-clogging conditions) through filter cap on top right of unit. DO NOT REMOVE CAP WHILE UNIT IS ACTIVATED. A sight glass front of unit provides visual means of checking coolant level. The drain plug is located directly below the sight glass.

Position magnetic holder/nozzle convenient to cutter. Turn selector switch to "mist", align spindle motor and open thumb screw nozzle control on nozzle. Direct flexible nozzle at cutter/work position. Spray mist has dual effect, cooling the cutter and moving chips away from cutter.

NOTE

A fine mist directed properly to the cutter will be satisfactory on the majority of materials. Do not reuse coolant.

or cut
slightly
and),
the
to rele
move
p out

and that brake lever (9) is released (push to rear).
Push spindle start button (2) to start motor
drive. To stop spindle, push stop button (3) and
move spindle brake lever (9) toward front of machine panel.

one speed of the motor to the other is obtained through switch control on the control panel.

which
at pe

button after changing the selector ring and activating start button must be followed or speed change will not take place. Electrical interlock prevents changing speeds without first actuating stop control. Continuous starting on high speed will kick out heater coils.

(12) +
Rim
of 14
side
mach
flam

Photo 11

and consistency of conditions) through DO NOT REMOVE. A slight gap is left for checking coolant directly below the


if/size convenient to "mist", start screw needle counter-clockwise at cutter/wheel effect, cooling the cutter.

jectly to the ry or the ma- Do not reuse

ased (push to rear on (2) to start motor stop button (3) at rear front of machine

r is obtained through seal.

selector ring must be locked prevents first actuator start-out heater



TO CHANGE SPEEDS—BELT

Having determined spindle speeds required for cutter, check speed plate (5) for belt position on pulleys. Grasp half-turn latch screws (4) (one each hand), rotate to unlock and swing shroud side panel to "down" position. Rotate locking screws (7) to left to release motor carrier slide, rotate handwheel (6) counter-clockwise to release belt to point where belt (10) may be moved over pulleys (8) and (11). Follow speed plate (5) directions for belt position on pulleys to obtain desired spindle speed.

NOTE

Belt is designed and arranged to drive on "cross-over" from driving pulley groove to driven pulley groove.

With belt in new pulley position, rotate handwheel (6) clockwise to apply tension to belt. Belt at proper tension can be deflected approximately

TO ADJUST RAM

Loosen front and rear ram clamping bolts (12) with open-end wrench furnished with machine. Ram positioning is accomplished through rotation of ram positioning gear shaft (13) located on right side of ram. Apply socket wrench furnished with machine to shaft extension. Retighten front and rear clamping bolts after ram adjustment.

NOTE

Do not disturb nut located behind rear

1/4" by pulling on belt nearest opening.

CAUTION

Too great a tension causes excessive belt wear.

Lock motor slide by rotating screws (7) to right. Grasp latching screws (4) (one each hand), swing panel to closed position and rotate latching screws to lock panel in closed position.

Step to front of machine. Push brake lever (9) to rear to release, check setting of motor speed selector (1) for proper setting and push "start" button (2).

LUBRICATION NOTE


Check level of lubrication in spindle roller whenever speed change is made. Refill is required. (Check daily).

clamping bolt. This mechanism is for aligning the ram.

CAUTION

Clean ram slide before moving. Foreign matter between surfaces will cause spindle to table top misalignment.

Photo 12



MANU
room
bein
HEAD
ESH 21
Wanda
side of
as was
side of
D) are
ould
hould
dual G
lockw
7. also
OWER
the po
s 25"
minute
e. wate
e. cont

Photo 13

LONGITUDINAL/CROSS FEED

MANUAL FEED--TABLE AND SADDLE

Table and saddle feed and positioning are accomplished by means of centrally located handwheels. Each handwheel of clutch-type (press in to engage) is equipped with adjustable micrometer dial.

The cross feed handwheel (4) is located at front right of knee. The table feed handwheel (7) extends at an angle from right front of saddle. The table clamping lever (5) is at center position. The two saddle clamping levers are located on the left side of the saddle (not illustrated).

Adjustable cross (8) and longitudinal stops (10) are provided.

CAUTION

When feeding or positioning under manual control, stops should be locked against limit pins to avoid damage. Stops cannot be positioned beyond limits of travel of cross or longitudinal motions (factory installed limit pins).

Prior to moving either axis, the clamp (6) should be released and location of adjustable stops should be checked. To feed saddle in, rotate handwheel (4) clockwise; to feed out, rotate counterclockwise. To feed table to right, rotate handwheel (7) clockwise; to feed left, rotate counterclockwise.

CAUTION

Do not engage and lock handwheels to shafts. This causes overload to motor when operating under power feed and is a hazardous practice which could cause personal injury.

NOTE

For normal power adjustment of knee, see section -- POWER ELEVATE -- KNEE.

POWER FEED--TABLE AND SADDLE

The machine is equipped with infinitely variable power feed to table and saddle. Feed range, 6" to 31" per minute. Rapid traverse rate 24" per minute (full feed rate). Feed rate control is by means of selector dial (2) located in lower left-hand corner of control panel on milling head.

Suggested sequences to engage power cross and longitudinal feeds:

- A. Release saddle and table clamps.
- B. Feed direction levers for table (3) and saddle (4) in neutral position.
- C. Machine power switch (main electrical control panel) in "on" position.
- D. Power downfeed switch (1) (when installed -- located in upper left corner of milling head control panel) in "click-off" position (electrically interlocked with table drive).
- E. Rotate feed rate selector dial (2) clockwise to desired setting.

NOTE

When dial is moved from stop-setting, the feed drive is set in motion to cross and longitudinal gear assemblies at - simultaneously -- ready for feed selection.

F. Select direction of motion of table or saddle desired. Table direction selector (3) and saddle direction selector (4) are directional. EITHER OR BOTH FEED DIRECTIONS can be engaged.

G. Adjust feed dial (2) setting for efficient cutting condition as determined by cutter diameter and material. FEED RATE CAN BE CHANGED IN THE CUT.

NOTE


Return dial to stop setting when feeding by hand.

H. Position longitudinal (10) and cross (8) adjustable stops -- if desired. When engaged in feed motion, the stops contact the actuating lever disengaging feed motion. Both longitudinal and cross motions are equipped with permanent limit stops (factory installed limit pins) determining maximum movement.

FEED PROTECTION

In the event that feed motion should be "stalled" through an accidental condition, an overload fuse (located in main electrical panel) will disconnect the feed motor control.

Photo 14



POWER ELEVATE - KNEE

The machine is provided with power actuated knee for positioning as standard equipment. This control is an assist to the operator in set-up and operation. Positioning is at a fixed rate of 20" per minute. Power elevate is through a separate motor --not connected to feed motor.

Directional control (1) for knee power elevate is conveniently located at upper left-hand corner of knee. Knee clamping lever (2) is located at upper right-hand corner of knee. Manual positioning handwheel (3) is located at left center position.

NOTE

Handwheel is clutch type--press in-ward knee to engage.

Suggested sequence of operation of power elevate control:

- A. Machine power switch (main electrical control panel) in "on" position.
- B. Release knee clamp (2) rotating lever clockwise (to left).

C. Actuate Bizer lubricator pump on left of knee.

D. Move control lever (1) in desired direction of travel. Switch is directional. If lever pulled knee will move up; pushed down, knee will move down. When released, control lever will return neutral position.

NOTE

Coasting of knee following release of lever is to be expected.


Usual operator practice is to position with a few thousandths with power elevate control & make final setting with manual handwheel. Manual handwheel has adjustable micrometer graduated dial.

CAUTION

Do not move feed limit stops or limit switches. These units have been located in position for maximum travel. Any change in the location can result in major damage to the feed components.

story
we in
knee
ate lit
O NOT

LUBRICATION



A--SPINDLE DOWNFEED GEAR BOX

Spindle downfeed gear box lubricated at factory. If disassembled, repack with Pate Oil Andox M375 grease.

58. LUBRICATION

The 2-30 Milling Machine must be properly lubricated before placing in operation and during operation to insure continued trouble-free operation. The illustrations locate lubrication points on the machine and the lubrication plate. Due to the advanced design, a minimum number of units require daily attention. However, adherence to the lubrication schedule is of major importance in obtaining maximum performance and long life of the machine.

1. SPINDLE DOWNFEED MOTOR

Spindle downfeed motor bearings are lubricated at factory--for two (2) year period. When repacking use Socomey EHB #4 or Sun Oil Prestige #42. Repeat at two (2) year intervals.

2. SPINDLE DOWNFEED GEAR CASE

Spindle downfeed gear case lubricated at factory--for two (2) year period. When re-packing use Socomey Mobilplex EP-24 or Sun Oil Prestige 740 AEP. Repeat at two (2) year intervals.

3, 4. SADDLE/TABLE AND KNEE/COLUMN

Saddle/table and knee/column slide lubrication pump and reservoir units located on left side of knee and saddle. Both hand pumps should be operated once, twice daily. Pull out handle and allow pump to return slowly. The oil level of both reservoirs should be checked daily and kept filled at all times.

NOTE: The two pumps described above are also the origin of lubrication for all internal rotating parts which are mounted in saddle or knee. Use Socomey Vactra #2 or Sun Oil SWL #90. Check daily.

5. POWER ELEVATE MOTOR

Power elevate motor bearings are permanently grease packed and do not require replenishment or change.

6. POWER ELEVATE GEAR BOX

The power elevate gear box is filled at factory for two (2) year period. When repacking the gear housing, cover must be disassembled. Use Socomey Mobilplex EP-24 or Sun Oil Prestige 740 AEP.

B--BEA

Vertical and long thrust bearings lubricated with Andox C

7. KNEE

Multiple running level is through moral of entire gear every six SWL #90.

8. KNEE

packed at operating rate by Oil Press

9. SPIN

through Use Socomey oil areas above and Oil SWL

Photo 17




Photo 18


OPTICAL MEASURING

The Versac measuring system (optional equipment) incorporated into the machine is a direct reading optical measuring instrument for indicating longitudinal and lateral position. Readings from the precision scales affixed to the machine table and saddle are transmitted through a lens system and projected onto illuminated direct-reading dials. Readings projected are in .025" intervals. Fine adjustment of the dial provides measurement to .0001".

The reader unit is mounted to a slide with 1" adjustment range. A clamp lever is provided on the reader slide for position clamping. Positioning of the reader slide permits operator to start from even number reading on reader (ref. 10,500) with .0000" on tenth scale.

NOTE

Considering the units of the system as components of a micrometer will greatly simplify the adjustments to the operator's mind. The scale readings in .025" increments are like the barrel of a micrometer and the double spiral reticle the thimble.



OPERATION

1. Turn on power switch for optic system (switch located on front face of machine electrical cabinet) which will illuminate readers.
2. Set up a reference point on the readers for the cutting tool in relationship to the workpiece.
3. Rotate outer ring of reader to position the double spiral reticle at .000" on the reticle scale.
4. Position the reader on its slide to bracket the .025" mark with the parallel lines of the double reticle and clamp.
5. Note the reading on the scale as this will be the reference point from which all measurements are made.

MOVING TABLE TO LEFT OF REFERENCE POINT

To move the machine table to the left of the reference point, you ADD the dimension to the reference point. Example: reference point 10,500", move 2,0194" to left. Rotate reticle clockwise until .015 mark lines up with line in reading area at bottom of dial. Then continue to rotate dial four di-

vision lines
table to left
line with the
tic. Total
MOVING TA

When
SUBTRACT
point. Ex: 2
2,0194" to
and bracket
lines (10,50

WIN
go
(2,01
in th

1. END MIL
opposite to k
the cut on
ling dia; on
because the
the spindle t
For an exact
down against
jectonable B
tenth are rel
sourced sag
operator is a
helix, left-h
better becau
along the th
the work.

2. RUNOUT
.001" will re
the secondary
on the work

3. RIGHT-RE
MILLS load s
reason why it
by many oper

4. TO ELDE
methods; lig
vary the age
nearer to the
cutter with a
less will othe

5. STRAIGHT
They mill a
helical flut
whole which h

6. TWO-FLU

Photo 19

vision lines for the .0004" total - .0154". Now move table to left with handwheel and bracket the 12.500 line with the parallel lines of the double spiral reticle. Total movement is 2.0154".

MOVING TABLE TO RIGHT OF REFERENCE POINT

When moving the machine table to right, you **SUBTRACT** the desired movement from the reference point. Example: reference point 10.500" - move 2.0154" to right. Move table to right from 10.500" and bracket 8.475" scale mark with double reticle lines (10.500" minus 2.025").

NOTE

With reticle scale at .000", you must go beyond the desired increment (2.0154") to the next .025" scale mark, in this case 8.4750". Then rotate re-

ticle scale clockwise to .0096" (0.025" minus .0154"). Now move table to LEFT and bracket 8.475 scale line.

NOTE

If reticle dial is at any reading beyond .000" which will permit subtraction of increment of movement, it is not necessary to go .025" beyond mark.

OPERATING NOTE

Dial cover should be in closed position whenever reader is not in use. Wipe off immediately any coolant, chips etc., accumulating on the readers and scales. Clean with soft tissue.

OPERATOR TIPS

1. **END MILLING CUTTERS** that have hand of helix opposite to hand of cut are ideal for profiling. When the cut is on the peripheral teeth only, as when milling disc cams, there is less tendency to chatter, because the thrust of the cut pushes the tool against the spindle thrust bearings. However, when used for an end cut, the left-right design throws the chips down against the work surface, which may be objectionable from a finish standpoint. Also, the end teeth are relatively inefficient because of the pronounced negative rake. On the other hand, if the operator is working to a scribed line, a right-hand helix, left-hand cut tool will allow him to see the line better because the chips and burr will be thrown down along the flute, rather than up on the top surface of the work.

2. **RUNOUT OF AN END MILLING CUTTER** (beyond .001") will result in a hammering effect and increase the tendency to chatter. The effect can be noticed on the work by a waviness in the surface finish.

3. **RIGHT-HAND CUT, RIGHT-HAND HELIX END MILLS** tend to pull out of their holders. This is one reason why the set screw type adapter is preferred by many operators over a spring collet.

4. **TO ELIMINATE CHATTER**, try one or all of these methods: tighten gibs, use a more rigid workholder, vary the speed and feed rate a bit, move the cutter nearer to the spindle. If all else fails, try using a cutter with a smaller number of teeth. Even a few less will often eliminate a harmonic.

5. **STRAIGHT-TOOTH END MILLS** do not "pull over". They mill a parallel and vertical keyway, whereas helical flute two-fluted end mills tend not produce slots which lean to one side.

6. **TWO-FLUTE END MILLS** excel where an end feed

is needed, as in plunging to depth in a keyway or pocket. Three and four-flute center cut mills will plunge, but not as freely as the two-flute.

7. **FOR SLOT MILLING** from an open end four-flute mills are better than two: the slot can be cut faster and more accurately in one pass.

8. **CARBIDE END MILLS** for keyway milling stand up longer, with less wear, if they have an odd number of teeth. With an odd number, the condition of one tooth just starting to cut and one just finishing directly across is eliminated. The pressures involved are reduced and likewise the cutting edge wear.

9. **END MILLS** are made to standard tolerances on cut diameter. These tolerances range from plus .000 minus .0015" to plus .000" minus .000" with each manufacturer choosing his own size within this range. Check the diameter of the end mill prior to attempting to mill a slot or keyway of a definite size.

10. **CLIMB OR CONVENTIONAL MILL**—Climb milling offers the advantage of better finish, greater feed per tooth, and a lower rate of tool wear than conventional milling. It is particularly suitable for heat-treated alloy steels and non-ferrous machining stainless steels because it gives better tool life and reduces work hardening.

It is not recommended for work having a hard scale, because abrasion quickly ruins the cutting edges. In addition, some very soft steels have a tendency to drag and tear. Climb milling should not be used on thin or frail workpieces.

Photo 21

the lathe cutters and are fine feed important should be starting

materials

is

materials

10 000
 125512
 127504
 131313
 131352
 131996
 131970
 13 7866
 13 4676
 13 4372
 13 1439
 13 2754
 13 2286
 13 1992
 13 1719
 13 1530
 13 1377
 13 1248
 13 1146
 13 764
 13 558
 13 762

CUTTING CHART

MATERIAL	Tensile Strength	Tangential Carbide Tantalum Carbide Ft. per Min.			High Speed Steel Ft. per Min.		
		Dry		Type of Coolant	Dry		Type of Coolant
		Wet	Wet		Wet	Wet	
Cast Iron Average Brinell 150-170	18000	240			90		
	26000	275			110		
	20000	275			70		
	28000	300			80		
	38000	210			65		
C. I. up to 1% Cr. 3 1/2% Ni. Brinell 200-210	36000	230			70		
	30000	175			62		
Semi Steel. 20 to 30% Steel Scrap with 2% Si. or Better. Brinell 170-195	30000	200			72		
	36000						
Steels	70000	220	220	Cutting Oil	160	170	Cutting Oil
	S. A. E. #1112						
	70000	240	240	Cutting Oil	175	185	Cutting Oil
	92000	260	260				
	High Sulphur Content						
#2 Bessemer High Sulphur	70000	270	300	Cutting Oil	165	175	Cutting Oil
	90000						
Ultra Cut High Manganese. Same Machinability as #2 Bessemer	90000	270	300	Cutting Oil	190	200	Cutting Oil
	110000						
Open Hearth Screw Stock S. A. E. #1120	70000	250	260	Cutting Oil	135	145	Soda Compound
	85000						
Soft Faging Steel S. A. E. #1020 Low Sulphur For Carbide	63000	240	250	Soda Compound	110	120	Soda Compound
	80000						
S. A. E. #1045	95000	200	240	Soda Compound	80	90	Soda Compound
	125000						
Alloy Steels 3 1/2% Ni. S. A. E. # 2315 for Gear Blanks	80000	165	175	Soda Compound	110	120	Soda Compound
	115000						
Chrome Ni. up to 50 Cr. and 1.5 Ni. S. A. E. #3120 For Heat Treated Bolts and Gear Blanks	80000	140	160	Soda Compound	100	100	Soda Compound
	110000						
Aluminum	19000	400	400	Kerosene & Lard Oil	220	230	Kerosene & Lard Oil
	Pure Cast Aluminum #43						
	Commercially Hard Temper Aluminum #2 SH	24000	240	250	Kerosene & Lard Oil	130	140
Dural High Tensile #17 ST.	58000	275	300	Soluble Oil	190	200	Soluble Oil
Copper	31000	180	200	Soluble Oil	100	120	Soluble Oil
	Copper One-Half Hard Commercial						
Brass	20000	400	600	Soluble Oil	200	220	
	Brass, Cast Yellow						
	Brass One-Half Hard Commercial						
Bronze	35000	250	280	Soluble Oil	130	150	Soluble Oil
	Bronze, Gun Metal						
	Bronze, Phosphor	50000	160	180	Soluble Oil	95	115

Photo 22

CAUSES OF MILLING PROBLEMS

PROBLEM	CAUSE	SOLUTION
Chatter	<ol style="list-style-type: none">1. Lack of rigidity in the machine, fixtures, arbor or workpiece.2. Cutting load too great. (Chip per tooth.)3. Dull cutter.4. Poor lubrication.5. Straight tooth cutter.6. Peripheral relief angle too great.7. Spindle backlash.	<ol style="list-style-type: none">1. Improve rigidity.2. Increase number of teeth in contact with workpiece.3. Resharpen.4. Improve lubrication.5. Use helical tooth cutter.6. Decrease relief angle.7. Adjust spindle spline backlash.
Cannot hold size.	<ol style="list-style-type: none">1. Cutting load too great causing deflection.2. May be due to chip packing.3. Chips causing misalignment of work.	<ol style="list-style-type: none">1. Increase number of teeth in contact with workpiece.2. Increase oil pressure or redirect flow so as to wash chips out of teeth.3. Brush all chips away before mounting new work piece.
Premature cutter dulling.	<ol style="list-style-type: none">1. Chip load too small.2. Insufficient coolant.	<ol style="list-style-type: none">1. Decrease number of teeth in contact with workpiece.2. Add blending oil to lubricant.
Poor surface finish.	<ol style="list-style-type: none">1. Feed too high.2. Dull tool.3. Speed too low.4. Insufficient number of cutter teeth.	<ol style="list-style-type: none">1. Decrease feed and increase speed.2. Resharpen.3. Increase S. F. M.4. Use cutter with more closely spaced teeth.
Cutter "Hops in"	<ol style="list-style-type: none">1. Peripheral relief too great.2. Dull tool.3. Improper speed.4. Screw backlash.	<ol style="list-style-type: none">1. Use recommended angles.2. Decrease rake angle.3. Check and adjust.4. Adjust anti-backlash.
Vibration	<ol style="list-style-type: none">1. Insufficient clearance causing rubbing.2. Machine at fault.	<ol style="list-style-type: none">1. Use recommended clearance angles.2. Check machine slides, gibs, etc..
Work burrishing.	<ol style="list-style-type: none">1. Cut is too light.2. Insufficient peripheral relief.3. Land too wide.	<ol style="list-style-type: none">1. Increase depth of cut.2. Increase peripheral relief angle.3. Decrease width of land.
Cutter burns.	<ol style="list-style-type: none">1. Insufficient lubricant.2. Speed too fast.	<ol style="list-style-type: none">1. Add more sulphur base oil.2. Decrease speed.
Teeth breaking.	<ol style="list-style-type: none">1. Feed too high.	<ol style="list-style-type: none">1. Decrease feed per tooth. May be possible to maintain rate by increasing the number of teeth.